



How to stream camera over network



Contents



STMicroelectronics reserves the right to modify the information contained in this document without notice.

A quality version of this page, approved on *10 April 2020*, was based off this revision.



1 Overview

This article will explain how to stream camera content over network thanks to GStreamer application on top of V4L2 Linux[®] kernel framework.

Capturing compressed JPEG pictures is an efficient way to send camera images to any local or remote player; JPEG pictures require a limited bandwidth while being fully interoperable.

Find below some examples of command lines allowing to capture a continuous JPEG stream while playing it using various multimedia players, either local or remote.



2 Local streaming

Here is an example of a local preview involving `V4l2-ctl` for JPEG pictures capture and `gst-play` GStreamer player for JPEG decoding and display. JPEG pictures are sent over a standard Linux pipe.

```
Board $> v4l2-ctl --set-parm=30;v4l2-ctl --set-fmt-video=width=640,height=480,
pixelformat=JPEG --stream-mmap --stream-count=1 --stream-to= 2>/dev/null | gst-play-1.0
"fd://0"
```

`--stream-to=` tells `V4l2-ctl` to output binary captured content to standard output, which is then sent to pipe `|`.

Special URI `fd://0` tells `gst-play` GStreamer player to read data from the pipe.

Note the `2>/dev/null` right after the `V4l2-ctl` command to remove the logs from console output.



3 UDP streaming

i Information

An internet connection is required, for example by plugging an ethernet cable on the [STM32MP157x-EV1 Evaluation board CN3 ethernet connector](#)

Get first the IP address **aa.bb.cc.dd** of the host PC using `ifconfig` command:

```
PC $> ifconfig | grep "inet addr"
inet addr:aa.bb.cc.dd Bcast:10.201.23.255 Mask:255.255.252.0
inet addr:127.0.0.1 Mask:255.0.0.0
```

Then fill the `host=` `udpsink` property with this IP address on the remote side:

```
Board $> v4l2-ctl --set-parm=30;v4l2-ctl --set-fmt-video=width=640,height=480,
pixelformat=JPEG --stream-mmap --stream-count=-1 --stream-to=- 2>/dev/null | gst-launch-
1.0 fdsrc ! jpegparse ! rtpjpegpay ! udpsink host=aa.bb.cc.dd port=5000
```

Then play the UDP stream on host PC:

```
PC $> gst-launch-1.0 udpsrc port=5000 ! application/x-rtp, encoding-name=JPEG !
rtpjpegdepay ! jpegparse ! decodebin ! autovideosink
```

A new window will popup on host PC displaying the camera content.

i Information

Due to SDP protocol signaling, this solution is not fully interoperable because it needs a dedicated GStreamer command line to be played on host side

Linux® is a registered trademark of Linus Torvalds.