

# U-Boot overview

Stable: 10.10.2019 - 18:16 / Revision: 10.10.2019 - 14:34

<b>Contents</b>	
1	Das U-Boot ..... 1
2	U-Boot overview ..... 2
2.1	SPL: FSBL for basic boot ..... 2
2.2	U-Boot: SSBL ..... 2
2.3	SPL phases ..... 3
2.4	U-Boot phases ..... 3
3	U-Boot configuration ..... 3
3.1	Kbuild ..... 4
3.2	Device tree ..... 5
4	U-Boot command line interface (CLI) ..... 5
4.1	Commands ..... 5
4.2	U-Boot environment variables ..... 7
4.2.1	bootcmd ..... 7
4.3	Generic Distro configuration ..... 8
4.4	U-Boot scripting capabilities ..... 8
5	U-Boot build ..... 9
5.1	Prerequisites ..... 9
5.1.1	ARM cross compiler ..... 9
5.2	Compilation ..... 10
5.3	Output files ..... 11
6	References ..... 11

## 1 Das U-Boot

Das **U-Boot** ("the Universal Boot Loader" or just U-Boot) is an open-source boot loader, which can be used on ST boards to initialize the platform and load the Linux<sup>®</sup> kernel.

- Official website: <https://www.denx.de/wiki/U-Boot>
- Official manual: [project documentation](#) and <https://www.denx.de/wiki/DULG/Manual>
- The official **source code** is available with [git repository](#) at [git.denx.de](https://git.denx.de)

```
PC $> git clone git://git.denx.de/u-boot.git
```

Reading the [README file](#) is recommended. It covers the following topics:


- the source file tree structure

- the meaning of the CONFIG defines
- instructions for building U-Boot
- a brief description of the Hush shell
- a list of common environment variables

## 2 U-Boot overview

The same U-Boot source can generate 2 pieces of firmware used in the [STM32 MPU boot chain](#): SPL and U-Boot

- Trusted boot chain: U-Boot as SSBL
- Basic boot chain: SPL as FSBL and U-Boot as SSBL



### 2.1 SPL: FSBL for basic boot

The **U-Boot SPL** or just **SPL** is the first stage boot loader (FSBL) for [the basic boot chain](#).

It is a small binary (bootstrap utility), generated from the U-Boot source, which fits in the internal and limited embedded RAM:

- It is loaded by the ROM code
- it does the initial CPU and board configuration: clocks and DDR
- it loads the SSBL (U-Boot) into DDR memory

### 2.2 U-Boot: SSBL

**U-Boot** is the default second stage boot loader (SSBL) for the STM32 MPU platforms for the 2 boot chains, [trusted and basic](#):

- it is configurable and expendable
- it has a simple command line interface (CLI), usually over a serial console port for interaction with the user
- it provides scripting capabilities
- it loads the kernel into RAM and passes control to the kernel
- it manages many internal and external devices like NAND, NOR, Ethernet, USB
- it has many supported features and commands for
  - file systems: FAT, UBI/UBIFS, JFFS
  - IP stack: FTP
  - display: LCD, HDMI, BMP for splashscreen
  - USB: host profile (mass storage) or device profile (DFU stack)

## 2.3 SPL phases

---

The **SPL** runs through the main following phases in SYSRAM:

- **board\_init\_f()**: init drivers up to DDR initialisation (minimal stack and heap: CONFIG\_SPL\_STACK\_R\_MALLOC\_SIMPLE\_LEN)
- configure heap in DDR (CONFIG\_SPL\_SYS\_MALLOC\_F\_LEN)
- **board\_init\_r()**: init other drivers activated in the SPL device tree
- load U-Boot (or Kernel in Falcon mode<sup>[1]</sup>: [README.falcon](#) ) and execute it

## 2.4 U-Boot phases

---

**U-Boot** runs through the following main phases in DDR:

- **Pre-relocation** initialization (common/board\_f.c): minimal init (cpu, clock, reset, ddr, console,...) running at the load address CONFIG\_SYS\_TEXT\_BASE
- **Relocation**: copy the code to the end of DDR
- **Post-relocation initialization**:(common/board\_r.c): init all the drivers
- **Execution of commands**: through autoboot (CONFIG\_AUTOBOOT) or console shell
  - execute the boot command (`bootcmd=CONFIG_BOOTCOMMAND` by default):  
for example, execute the command 'bootm' to:
    - load and check images (kernel, device tree, ramdisk....)
    - fixup kernel device tree
    - install secure monitor (optional)
    - pass control to the Linux kernel (or other target application)

## 3 U-Boot configuration

---

The U-Boot binary configuration is based on

- **Kbuild infrastructure** (as in [Linux Kernel](#), you can use "make menuconfig" in U-Boot)  
The configurations are based on:
  - options defined in Kconfig files (CONFIG\_ compilation flags)
  - the selected configuration file = [configs/stm32mp\\*\\_defconfig](#)
- **other compilation flags** defines in [include/configs/stm32mp\\*.h](#)  
the file name is configured by CONFIG\_SYS\_CONFIG\_NAME  
(these flags are progressively migrating to Kconfig)  
for stm32mp157: we use [include/configs/stm32mp1.h](#) file
- **DeviceTree** = U-Boot and SPL binaries include a device tree blob which is parsed at run time

All the configuration flags (CONFIG\_) are described in the source code: the [README](#) file or [documentation directory](#)

example: CONFIG\_SPL => activate the SPL compilation.

Hence to compile U-Boot, you need to [select the <target>](#) and [the device tree](#) for the board to select a predefined configuration.

See [#U-Boot\\_build](#) for examples.

## 3.1 Kbuild

The U-Boot build system is based on [configuration symbols as the kernel](#) (defined in Kconfig files), and selected values are stored in a **.config** file in the build directory, with the same makefile target.

- select pre-defined configuration (defconfig file, in [configs directory](#) ) and generate the first **.config**

```
PC $> make <config>_defconfig
```

- change U-Boot compile configuration (modify .config) using one of the 5 make command

```
PC $> make menuconfig --> menu based program
PC $> make config --> line-oriented configuration
PC $> make xconfig --> QT program[2]
PC $> make gconfig --> GTK program
PC $> make nconfig --> ncurses menu based program
```

You can then compile U-Boot with the updated .config.

Warning: modification is only done locally in the build directory, it is lost after a "make distclean"

So if you want to use your configuration as defconfig:

```
PC $> make savedefconfig
```

This target saves the current config as a defconfig file in the build directory, and can be compared with the predefined configuration (configs/stm32mp\*defconfig).

The other makefile targets are :

```
PC $> make help
....
Configuration targets:
config      - Update current config utilising a line-oriented program
nconfig     - Update current config utilising a ncurses menu based
              program
menuconfig  - Update current config utilising a menu based program
xconfig     - Update current config utilising a Qt based front-end
gconfig     - Update current config utilising a GTK+ based front-end
oldconfig   - Update current config utilising a provided .config as base
localmodconfig - Update current config disabling modules not loaded
localyesconfig - Update current config converting local mods to core
defconfig   - New config with default from ARCH supplied defconfig
savedefconfig - Save current config as ./defconfig (minimal config)
allnoconfig - New config where all options are answered with no
allyesconfig - New config where all options are accepted with yes
allmodconfig - New config selecting modules when possible
alldefconfig - New config with all symbols set to default
randconfig  - New config with random answer to all options
listnewconfig - List new options
olddefconfig - Same as oldconfig but sets new symbols to their
              default value without prompting
```

## 3.2 Device tree

See [doc/README.fdt-control](#)

The board device tree, with the same binding as the kernel, is integrated with the SPL and U-Boot binaries:

- appended at the end of the code by default (CONFIG\_OF\_SEPARATE)
- embedded in binary (CONFIG\_OF\_EMBED): useful for debug, allows easy elf file loading

A default device tree is defined in the defconfig file (with CONFIG\_DEFAULT\_DEVICE\_TREE).

You can also select another supported device tree with the make flag DEVICE\_TREE for stm32mp32 boards the file are: [arch/arm/dts/stm32mp\\*.dts](#)

```
PC $> make DEVICE_TREE=<dts-file-name>
```

or you can provide a precompiled device tree blob (with EXT\_DTBO option)

```
PC $> make EXT_DTBO=boot/<dts-file-name>.dtb
```

The SPL device tree is also generated from this device tree; but to reduce its size, the U-Boot makefile uses the fdtgrep tool to parse the full U-Boot DTB and identify all the drivers needed by SPL.

To do this, U-Boot uses some specific device-tree flags to specify if the associated driver is initialized prior to U-Boot relocation and/or if the associated node is present in SPL :

- **u-boot,dm-pre-reloc** => present in SPL, initialized before relocation in U-Boot
- **u-boot,dm-spl** => present in SPL

In the device tree used by U-Boot, these flags **need to be added in each node** used in SPL or in U-Boot before relocation but also for each used handle (clock, reset, pincontrol).

## 4 U-Boot command line interface (CLI)

see [U-Boot Command Line Interface](#)

If CONFIG\_AUTOBOOT is activated, to enter in this console, you have CONFIG\_BOOTDELAY seconds (2s by default) before `bootcmd` execution (CONFIG\_BOOTCOMMAND) by pressing any key when the line below is displayed.

```
Hit any key to stop autoboot: 2
```

### 4.1 Commands

The commands are defined `cmd/*.c` , they are activated under associated configuration flag **CONFIG\_CMD\_\***.

Use the command **help** in the U-Boot shell to list the available commands on your device.

List of commands extracted from [U-Boot Manual](#) (**not-exhaustive**):

- [Information Commands](#)
  - bdfinfo - print Board Info structure
  - coninfo - print console devices and informations
  - flinfo - print FLASH memory information
  - iminfo - print header information for application image
  - help - print online help
- [Memory Commands](#)
  - base - print or set address offset
  - crc32 - checksum calculation
  - cmp - memory compare
  - cp - memory copy
  - md - memory display
  - mm - memory modify (auto-incrementing)
  - mtest - simple RAM test
  - mw - memory write (fill)
  - nm - memory modify (constant address)
  - loop - infinite loop on address range
- [Flash Memory Commands](#)
  - cp - memory copy
  - flinfo - print FLASH memory information
  - erase - erase FLASH memory
  - protect - enable or disable FLASH write protection
  - mtdparts - define a Linux compatible MTD partition scheme
- [Execution Control Commands](#)
  - source - run script from memory
  - bootm - boot application image from memory
  - go - start application at address 'addr'
- [Download Commands](#)
  - bootp - boot image via network using BOOTP/TFTP protocol
  - dhcp - invoke DHCP client to obtain IP/boot params
  - loadb - load binary file over serial line (kermit mode)
  - loads - load S-Record file over serial line
  - rarpboot- boot image via network using RARP/TFTP protocol
  - tftpboot- boot image via network using TFTP protocol
- [Environment Variables Commands](#)
  - printenv- print environment variables
  - saveenv - save environment variables to persistent storage
  - setenv - set environment variables
  - run - run commands in an environment variable
  - bootd - boot default, i.e., run 'bootcmd'
- [Flattened Device Tree support](#)
  - fdt addr - select FDT to work on
  - fdt list - print one level
  - fdt print - recursive print

- fdt mknod - create new nodes
- fdt set - set node properties
- fdt rm - remove nodes or properties
- fdt move - move FDT blob to new address
- fdt chosen - fixup dynamic info
- [Special Commands](#)
  - i2c - I2C sub-system
- [Storage devices](#)
- [Miscellaneous Commands](#)
  - echo - echo args to console
  - reset - Perform RESET of the CPU
  - sleep - delay execution for some time
  - version - print monitor version

To add a new command, see [doc/README.commands](#)

## 4.2 U-Boot environment variables

---

The U-Boot behavior is configured with environment variables.

see [Manual](#) and [README / Environment Variables](#)

By default the env is NOT saved (CONFIG\_ENV\_IS\_NOWHERE), only the default environment is used (saveenv command is not working)

You can modify this default environment by changing the content of CONFIG\_EXTRA\_ENV\_SETTINGS in your configuration file (for example ./include/configs/stm32mp1.h) (see [README / - Default Environment](#)).

You can also choose one location with configuration flags:

- CONFIG\_ENV\_IS\_IN\_MMC
- CONFIG\_ENV\_IS\_IN\_FLASH
- CONFIG\_ENV\_IS\_IN\_SPI
- CONFIG\_ENV\_IS\_IN\_FAT
- CONFIG\_ENV\_IS\_IN\_NAND
- CONFIG\_ENV\_IS\_IN\_UBI
- CONFIG\_ENV\_IS\_IN\_EEPROM

### 4.2.1 bootcmd

---

Autoboot command: defines the command executed when U-Boot starts (CONFIG\_BOOTCOMMAND).

But you can change this variable in CONFIG\_EXTRA\_ENV\_SETTINGS (after BOOTENV macro needed for [#Generic Distro configuration](#)).

```
#define CONFIG_EXTRA_ENV_SETTINGS \  
    "stdin=serial\0" \  
    "stdout=serial\0" \  
    "stderr=serial\0" \  
    "kernel_addr_r=0xc2000000\0" \  
    "fdt_addr_r=0xc4000000\0" \  
    "
```

```
"scriptaddr=0xc4100000\0" \
"pxefile_addr_r=0xc4200000\0" \
"splashimage=0xc4300000\0" \
"ramdisk_addr_r=0xc4400000\0" \
"fdt_high=0xffffffff\0" \
"initrd_high=0xffffffff\0" \
BOOTENV\
"bootcmd=run bootcmd_mmc0\0"
```

### 4.3 Generic Distro configuration

see [doc/README.distro](#)

This feature is activated for ST boards (CONFIG\_DISTRO\_DEFAULTS):

- one boot command (bootcmd\_XXX) exists for each bootable device
- U-Boot is independent of the Linux distribution used.
- bootcmd is defined in `./include/config_distro_bootcmd.h`

With DISTRO the default command executed: `include/config_distro_bootcmd.h`

```
bootcmd=run distro_bootcmd
```

This script will try any device found in the variable 'boot\_targets' and execute the associated bootcmd.

Example for device mmc0, mmc1, mmc2, pxe and ubifs:

```
bootcmd_mmc0=setenv devnum 0; run mmc_boot
bootcmd_mmc1=setenv devnum 1; run mmc_boot
bootcmd_mmc2=setenv devnum 2; run mmc_boot
bootcmd_pxe=run boot_net_usb_start; dhcp; if pxe get; then pxe boot; fi
bootcmd_ubifs0=setenv devnum 0; run ubifs_boot
```

U-Boot searches for a configuration file **extlinux.conf** in a bootable device, this file defines the kernel configuration to use:

- bootargs
- kernel + device tree + ramdisk files (optional)
- FIT image

### 4.4 U-Boot scripting capabilities

"Script files" are command sequences that will be executed by U-Boot's command interpreter; this feature is especially useful when you configure U-Boot to use a real shell (hush) as command interpreter.

See [U-Boot script manual](#) for example.

## 5 U-Boot build

### 5.1 Prerequisites

You need:

- a PC with Linux and tools:
  - see [PC\\_prerequisites](#)
  - [#ARM cross compiler](#)
- U-Boot source code
  - the latest STMicroelectronics U-Boot version
    - tar.xz file from Developer Package (for example [STM32MP1](#))
    - from GITHUB<sup>[3]</sup>, with git command

```
PC $> git clone https://github.com/STMicroelectronics/u-boot
```

- from the Mainline U-Boot in official GIT repository <sup>[4]</sup>

```
PC $> git clone http://git.denx.de/u-boot.git
```

#### 5.1.1 ARM cross compiler

You need to have a cross compiler <sup>[5]</sup> installed on your Host (X86\_64, i686, ...) for the targeted Device architecture = ARM, the environment variables (\$PATH and \$CROSS\_COMPILE) need to be configured in your shell.

You can use gcc for ARM, available in:

1. the SDK toolchain  
See [Cross-compile with OpenSTLinux SDK](#), PATH and CROSS\_COMPILE are automatically updated.
2. an existing package (for example, on Ubuntu/Debian: (**PC \$>** sudo apt-get install gcc-arm-linux-gnueabi))
3. an existing toolchain:
  - gcc v8 toolchain provided by arm (<https://developer.arm.com/open-source/gnu-toolchain/gnu-a/downloads/>)
  - gcc v7 toolchain provided by linaro: (<https://www.linaro.org/downloads/>)

for example: **gcc-linaro-7.2.1-2017.11-x86\_64\_arm-linux-gnueabi.tar.xz**

from <https://releases.linaro.org/components/toolchain/binaries/7.2-2017.11/arm-linux-gnueabi/> unzip it in \$HOME,

and you need to update your environment:

```
PC $> export PATH=$HOME/gcc-linaro-7.2.1-2017.11-x86_64_arm-linux-gnueabi/bin:$PATH
PC $> export CROSS_COMPILE=arm-linux-gnueabi-
```

## 5.2 Compilation

In the U-Boot source directory, you need to select the <target> and the <device tree> for your configuration and then execute the "make all" command.

```
PC $> make <target>_defconfig
PC $> make DEVICE_TREE=<device-tree> all
```

**KBUILD\_OUTPUT** can be used optionally to change the output directory if you want to compile several targets or don't compile in the source directory, for example:

```
PC $> export KBUILD_OUTPUT=./build/basic
```

**DEVICE\_TREE** can be also exported to your environment when you support only one board, for example:

```
PC $> export DEVICE_TREE=stm32mp157c-ev1
```

For all the stm32mp15 family, we manage 3 configurations:

- stm32mp15\_trusted\_defconfig: [trusted boot chain](#), U-Boot (without SPL) is unsecure and uses Secure monitor from TF-A
- stm32mp15\_optee\_defconfig: [trusted boot chain](#), U-Boot (without SPL) is unsecure and uses Secure monitor from SecureOS = [OP-TEE](#)
- stm32mp15\_basic\_defconfig: [basic boot chain](#), with an SPL as FSBL, U-BOOT is secure and installs monitor with PSCI

The board diversity is only managed with the device tree.

Examples from [STM32MP15 U-Boot](#):

```
PC $> export KBUILD_OUTPUT=./build/basic
PC $> make stm32mp15_basic_defconfig
PC $> make DEVICE_TREE=stm32mp157c-<board> all
```

```
PC $> export KBUILD_OUTPUT=./build/trusted
PC $> make stm32mp15_trusted_defconfig
PC $> make DEVICE_TREE=stm32mp157c-<board> all
```

```
PC $> export KBUILD_OUTPUT=./build/trusted
PC $> export DEVICE_TREE=stm32mp157c-ev1
PC $> make stm32mp15_trusted_defconfig
PC $> make all
```

Use help to list other targets:

```
PC $> make help
```

## 5.3 Output files

---

The resulting U-Boot files are present in your build directory (U-Boot or KBUILD\_OUTPUT) and SPL Images are in the spl subdirectory.

STM32 image format (\*.stm32) is managed by mkimage U-Boot tools and is requested by boot ROM (for basic boot chain) or by TF-A (for trusted boot chain).

- **u-boot.stm32** : U-Boot binary with STM32 image header => SSBL for Trusted boot chain
- **u-boot.img** : U-Boot binary with ulmage header => SSBL for Basic boot chain
- u-boot : elf file, used to debug with gdb
- **spl/u-boot-spl.stm32** : SPL binary with STM32 image header => FSBL for Basic boot chain
- spl/u-boot-spl : elf file, used to debug with gdb

## 6 References

---

1. ↑ <https://www.denx.de/wiki/pub/U-Boot/MiniSummitELCE2013/2013-ELCE-U-Boot-Falcon-Boot.pdf>
2. ↑ <https://en.wikipedia.org/wiki/Xconfig>
3. ↑ <https://github.com/STMicroelectronics/u-boot>
4. ↑ <http://git.denx.de/u-boot.git> or <https://github.com/u-boot/u-boot>
5. ↑ [https://en.wikipedia.org/wiki/Cross\\_compiler](https://en.wikipedia.org/wiki/Cross_compiler)

Secondary Program Loader, *Also known as **U-Boot SPL***

Second Stage Boot Loader

First Stage Boot Loader

Random Access Memory

Read Only Memory

Central processing unit

Doubledata rate (memory domain)

Microprocessor Unit

High-Definition Multimedia Interface (HDMI standard)

Device Firmware Upgrade

Device Tree Binary (or Blob)

Memory Technology Device

Trivial File Transfer Protocol ([https://en.wikipedia.org/wiki/Trivial\\_File\\_Transfer\\_Protocol](https://en.wikipedia.org/wiki/Trivial_File_Transfer_Protocol))

Inter-Integrated Circuit

MultimediaCard

Serial Peripheral Interface

Electrically-erasable programmable read-only memory

Initial ramdisk ([https://en.wikipedia.org/wiki/Initial\\_ramdisk](https://en.wikipedia.org/wiki/Initial_ramdisk)) - NEW

Software development kit

Trusted Firmware for Arm Cortex-A

Power State Coordination Interface