


1.1.2.2 Develop on Arm® Cortex®-A7

Stable: 08.10.2019 - 09:56 / Revision: 08.10.2019 - 09:55



This module guides you to install the STM32MP1 Developer Package to develop on Arm® Cortex®-A7 side. The STM32MP1 Developer Package contains (for the Arm® Cortex®-A7 side) the Software Development Kit (SDK) that allows you to cross compile your own application or to rebuild the Linux® kernel.



To complete this module, it is assumed a Linux PC running Ubuntu 16.04 is used.

[Back](#)

[Overview](#)

[Next](#)

Permission error

You do not have permission to read this page, for the following reason:

You are not allowed to execute the action you have requested.

Permission error

You do not have permission to read this page, for the following reason:

You are not allowed to execute the action you have requested.

Permission error

You do not have permission to read this page, for the following reason:

You are not allowed to execute the action you have requested.