



How to get name and current status of a DRM connector

How to get name and current status of a DRM connector



How to get name and current status of a DRM connector

Use the following command to get the DRM connector names and associated status:

```
Board $> for p in /sys/class/drm/*/status; do con=${p%/status}; echo -n "${con#*/card?-}:"  
"; cat $p; done
```

Result example:

```
DSI-1: connected  
HDMI-A-1: connected
```

Direct Rendering Manager (kernel module that gives direct hardware access to DRI clients, find more information on official DRI web site <http://dri.freedesktop.org/wiki/DRM>)

Display Serial Interface (MIPI[®] Alliance standard)

High-Definition Multimedia Interface (HDMI standard)