



Install STM32CubeMP1 package

Install STM32CubeMP1 package



A quality version of this page, approved on *5 July 2021*, was based off this revision.



1 Overview

This stage explains how to install the STM32CubeMP1 package.



2 Install STM32CubeMP1 package

The software package is provided AS IS, and by downloading it, you agree to be bound to the terms of the software license agreement (SLA). The detailed content licenses can be found [here](#).



To download a package, it is recommended to be logged in to your "myst" account [1]. If, trying to download, you encounter a "403 error", you could try to empty your browser cache to workaround the problem. We are working on the resolution of this problem.
We apologize for this inconvenience


- Download en.STM32Cube_FW_MP1_V1.4.0.zip to the following directory:
\$HOME/STM32MPU_workspace/STM32MP15-Ecosystem-v3.0.0/Developer-Package
- Uncompress the archive file to get the STM32CubeMP1 Package

```
PC $> unzip en.STM32Cube_FW_MP1_V1.4.0.zip
```



3 STM32CubeMP1 package structure

The STM32CubeMP1 Package is located in your `$HOME/STM32MPU_workspace/STM32MP15-Ecosystem-v3.0.0/Developer-Package` directory. It is named `STM32Cube_FW_MP1_V1.4.0`:



Board support package

Cortex Microcontroller Software Interface Standard

Hardware Abstraction Layer