



Menuconfig or how to configure kernel



## Contents

---

1. Menuconfig or how to configure kernel .....	
2. Linux.README.HOW TO.txt .....	
3. How to cross-compile with the Developer Package .....	
4. How to cross-compile with the Distribution Package .....	



# Menuconfig or how to configure kernel

Stable: 03.05.2019 - 14:50 / Revision: 02.05.2019 - 16:19

A quality version of this page, [accepted](#) on 3 May 2019, was based off this revision.

Template:ArticleMainWriter Template:ArticleApprovedVersion

## Contents

1 Linux configuration genericity .....	3
2 Menuconfig and Developer Package .....	5
3 Menuconfig and Distribution Package .....	7
4 References .....	7

## 1 Linux configuration genericity

The process of building a kernel has two parts: configuring the kernel options and building the source with those options.

The Linux<sup>®</sup> kernel configuration is found in the generated file: `.config`.

`.config` is the result of configuring task which is processing platform `defconfig` and fragment files if any.

For OpenSTLinux distribution the `defconfig` is located into the kernel source code and fragments into `stm32mp` BSP layer :

- `arch/arm/configs/multi_v7_defconfig`

Every new kernel version brings a bunch of new options, we do not want to back port them into a specific `defconfig` file each time the kernel releases, so we use the same `defconfig` file based on ARM SoC v7 architecture.

STM32MP1 specificities are managed with fragments config files.

- `meta-st/meta-st-stm32mp/recipes-kernel/linux/linux-stm32mp/<kernel version>/fragment-*.config`

`.config` result is located in the build folder:

- `build-openstlinuxweston-stm32mp1/tmp-glibc/work/stm32mp1-openstlinux_weston-linux-gnueabi/linux-stm32mp/4.14-48/linux-stm32mp1-standard-build/.config`

**To modify the kernel options, it is not recommended to edit this file directly.**

- A user runs either a text-mode :

```
PC $> make config
starts a character based question and answer session (Figure 1)
```

```
PC $> make menuconfig
starts a terminal-oriented configuration tool (using ncurses) (Figure 2)
The ncurses text version is more popular and is run with the make menuconfig option.
Wikipedia Menuconfig[1] also explains how to "navigate" within the configuration menu,
and highlights main key strokes.
```

```
[greg@shamp linux-2.5]$ make config
make[1]: `scripts/kconfig/conf' is up to date.
./scripts/kconfig/conf arch/i386/Kconfig
#
# using defaults found in .config
#
*
*
* Linux Kernel Configuration
*
*
* Code maturity level options
*
Prompt for development and/or incomplete code/drivers (EXPERIMENTAL) [Y/n/?]
```

Figure 1. Configuring the kernel with make config

- or a graphical kernel configurator :

```
PC $> make
xconfig
starts a X based
configuration tool
(Figure 3)
```

Ultimately these configuration tools edit the .config file.

An option indicates either some driver is built into the kernel ("=y") or will be built as a module ("=m") or is not selected.

The unselected state can either be indicated by a line starting with "#" (e.g. "# CONFIG\_SCSI is not set") or by the absence of the relevant line from the .config file.

The 3 states of the main selection option for the SCSI subsystem (which actually selects the SCSI mid level driver) follow. Only one of these should appear in an actual .config file:



Figure 2. Make menuconfig makes it easier to back up and correct mistakes

```
CONFIG_SCSI=m
# CONFIG_SCSI is not set
```

```
CONFIG_SCSI=y
```




Figure 3. The Qt-Based make xconfig

## 2 Menuconfig and Developer Package

For this use case, the prerequisite is that OpenSTLinux SDK has been installed and configured.

To verify if your cross-compilation environment has been put in place correctly, run the following command:

```
PC $> set | grep CROSS
CROSS_COMPILE=arm-openstlinux_weston-linux-gnueabi-
```

For more details, refer to [<Linux kernel installation directory>/README.HOW\\_TO.txt](#) helper file (the latest version of this helper file is also available in this user guide: [README.HOW\\_TO.txt](#)).

- Go to the [<Linux kernel build directory>](#)

```
PC $> cd <Linux kernel build directory>
```

- Save initial configuration (to identify later configuration updates)

```
PC $> make arch=ARM savedefconfig
Result is stored in defconfig file
PC $> cp defconfig defconfig.old
```

- Start the Linux kernel configuration menu

```
PC $> make arch=ARM menuconfig
```

- Navigate forwards or backwards directly between feature
  - un/select, modify feature(s) you want
  - When the configuration is OK : exit and save the new configuration

useful keys to know:

**enter**: enter in config subdirectory

**space**: hit several times to either select [\*], select in module [m] or unselect [ ]

**/:** to search for a keyword, this is useful to navigate in tree

**?:** to have more information on selected line

- Compare the old and new config files after operating modifications with menuconfig

```
PC $> make arch=ARM savedefconfig
```

Retrieve configuration updates by comparing the new defconfig and the old one

```
PC $> meld defconfig defconfig.old
```

- Cross-compile the Linux kernel (please check the load address in the *README.HOW\_TO.txt* helper file)

```
PC $> make arch=ARM uImage LOADADDR=<loadaddr of kernel>
```

```
PC $> cp arch/arm/boot/uImage install_artifact/boot/
```

- Update the Linux kernel image on board

```
PC $> scp install_artifact/boot/uImage root@<board ip address>:/boot/
```



If the */boot* mounting point doesn't exist yet, please see [how to create a mounting point](#)

- Reboot the board

```
Board $> cd /boot; sync; systemctl reboot
```

Note that this use case modifies the configuration file in the Linux kernel build directory, not in the Linux kernel source directory: this is a temporary modification useful for a prototyping.

- To make this temporary modification permanent, the delta between defconfig and defconfig.old must be saved in a configuration fragment file (fragment-\*.config) based on fragment.cfg file, and the Linux kernel configuration /compilation steps must be re-executed (as explained in the *README.HOW\_TO.txt* helper file).

## 3 Menuconfig and Distribution Package

- Start the Linux kernel configuration menu

```
PC $> bitbake virtual/kernel -c menuconfig
```

- Navigate forwards or backwards directly between feature
  - un/select, modify feature(s) you want
  - When the configuration is OK : exit and save the new configuration

useful keys to know:

**enter**: enter in config subdirectory

**space**: hit several times to either select **[\*]**, select in module **[m]** or unselect **[ ]**

**/:** to search for a keyword, this is usefull to navigate in tree

**?:** to have more information on selected line

- Cross-compile the Linux kernel

```
PC $> bitbake virtual/kernel
```

- Update the Linux kernel image on board

```
PC $> scp <build dir>/tmp-glibc/deploy/images/<machine name>/uImage root@<board ip address>:/boot
```



If the `/boot` mounting point does not exist yet, please see [how to create a mounting point](#)

- Reboot the board

```
Board $> cd /boot; sync; systemctl reboot
```

Note that this use case modifies the configuration file in the Linux kernel build directory, not in the Linux kernel source directory: this is a temporary modification useful for a prototyping.

- To make this temporary modification permanent, it must be saved in a configuration fragment file (fragment-\*.config) based on **fragment.cfg** file, and the Linux kernel configuration/compilation steps must be re-executed: **bitbake <name of kernel recipe>**.

## 4 References

- [Wikipedia Menuconfig](#)



Board support package

Software development kit (A programming package that enables a programmer to develop applications for a specific platform.)

## Menuconfig or how to configure kernel

Template:ArticleMainWriter Template:ArticleApprovedVersion

### Contents

1 Linux configuration genericity .....	8
2 Menuconfig and Developer Package .....	10
3 Menuconfig and Distribution Package .....	12
4 References .....	12

# 1 Linux configuration genericity

The process of building a kernel has two parts: configuring the kernel options and building the source with those options.

The Linux<sup>®</sup> kernel configuration is found in the generated file: `.config`.

`.config` is the result of configuring task which is processing platform `defconfig` and fragment files if any.

For OpenSTLinux distribution the `defconfig` is located into the kernel source code and fragments into `stm32mp` BSP layer :

- `arch/arm/configs/multi_v7_defconfig`

Every new kernel version brings a bunch of new options, we do not want to back port them into a specific `defconfig` file each time the kernel releases, so we use the same `defconfig` file based on ARM SoC v7 architecture.

STM32MP1 specificities are managed with fragments config files.

- `meta-st/meta-st-stm32mp/recipes-kernel/linux/linux-stm32mp/<kernel version>/fragment-*.config`

`.config` result is located in the build folder:

- `build-openstlinuxweston-stm32mp1/tmp-glibc/work/stm32mp1-openstlinux_weston-linux-gnueabi/linux-stm32mp/4.14-48/linux-stm32mp1-standard-build/.config`

**To modify the kernel options, it is not recommended to edit this file directly.**

- A user runs either a text-mode :

```
PC $> make config
starts a character based question and answer session (Figure 1)
```

```
[greg@shamp linux-2.5]$ make config
make[1]: `scripts/kconfig/conf' is up to date.
./scripts/kconfig/conf arch/i386/Kconfig
#
# using defaults found in .config
#
*
*
* Linux Kernel Configuration
*
*
* Code maturity level options
*
Prompt for development and/or incomplete code/drivers (EXPERIMENTAL) [Y/n/?]
```

Figure 1. Configuring the kernel with make config

PC \$> make menuconfig starts a terminal-oriented configuration tool (using ncurses) (Figure 2) The ncurses text version is more popular and is run with the make menuconfig option. **Wikipedia Menuconfig<sup>[1]</sup>** also explains how to "navigate" within the configuration menu, and highlights main key strokes.




Figure 2. Make menuconfig makes it easier to back up and correct mistakes

- or a graphical kernel configurator :

PC \$> make xconfig starts a X based configuration tool (Figure 3)

Ultimately these configuration tools edit the .config file.

An option indicates either some driver is built into the kernel ("=y") or will be built as a module ("=m") or is not selected.

The unselected state can

either be indicated by a line starting with "#" (e.g. "# CONFIG\_SCSI is not set") or by the absence of the relevant line from the .config file.

The 3 states of the main selection option for the SCSI subsystem (which actually selects the SCSI mid level driver) follow. Only one of these should appear in an actual .config file:

```
CONFIG_SCSI=y
CONFIG_SCSI=m
# CONFIG_SCSI is not set
```




Figure 3. The Qt-Based make xconfig

## 2 Menuconfig and Developer Package

For this use case, the prerequisite is that OpenSTLinux SDK has been installed and configured.

To verify if your cross-compilation environment has been put in place correctly, run the following command:

```
PC $> set | grep CROSS
CROSS_COMPILE=arm-openstlinux_weston-linux-gnueabi-
```

For more details, refer to [<Linux kernel installation directory>/README.HOW\\_TO.txt](#) helper file (the latest version of this helper file is also available in this user guide: [README.HOW\\_TO.txt](#)).

- Go to the [<Linux kernel build directory>](#)

```
PC $> cd <Linux kernel build directory>
```

- Save initial configuration (to identify later configuration updates)

```
PC $> make arch=ARM savedefconfig
Result is stored in defconfig file
PC $> cp defconfig defconfig.old
```

- Start the Linux kernel configuration menu

```
PC $> make arch=ARM menuconfig
```

- Navigate forwards or backwards directly between feature
  - un/select, modify feature(s) you want
  - When the configuration is OK : exit and save the new configuration

useful keys to know:

**enter**: enter in config subdirectory

**space**: hit several times to either select [\*], select in module [m] or unselect [ ]

**/**: to search for a keyword, this is usefull to navigate in tree

**?**: to have more information on selected line

- Compare the old and new config files after operating modifications with menuconfig

```
PC $> make arch=ARM savedefconfig
```

Retrieve configuration updates by comparing the new defconfig and the old one

```
PC $> meld defconfig defconfig.old
```

- Cross-compile the Linux kernel (please check the load address in the *README.HOW\_TO.txt* helper file)

```
PC $> make arch=ARM uImage LOADADDR=<loadaddr of kernel>  
PC $> cp arch/arm/boot/uImage install_artifact/boot/
```

- Update the Linux kernel image on board

```
PC $> scp install_artifact/boot/uImage root@<board ip address>:/boot/
```



If the */boot* mounting point doesn't exist yet, please see [how to create a mounting point](#)

- Reboot the board

```
Board $> cd /boot; sync; systemctl reboot
```

Note that this use case modifies the configuration file in the Linux kernel build directory, not in the Linux kernel source directory: this is a temporary modification useful for a prototyping.

- To make this temporary modification permanent, the delta between defconfig and defconfig.old must be saved in a configuration fragment file (fragment-\*.config) based on fragment.cfg file, and the Linux kernel configuration /compilation steps must be re-executed (as explained in the *README.HOW\_TO.txt* helper file).

## 3 Menuconfig and Distribution Package

- Start the Linux kernel configuration menu

```
PC $> bitbake virtual/kernel -c menuconfig
```

- Navigate forwards or backwards directly between feature
  - un/select, modify feature(s) you want
  - When the configuration is OK : exit and save the new configuration

useful keys to know:

**enter**: enter in config subdirectory

**space**: hit several times to either select **[\*]**, select in module **[m]** or unselect **[ ]**

**/:** to search for a keyword, this is usefull to navigate in tree

**?:** to have more information on selected line

- Cross-compile the Linux kernel

```
PC $> bitbake virtual/kernel
```

- Update the Linux kernel image on board

```
PC $> scp <build dir>/tmp-glibc/deploy/images/<machine name>/uImage root@<board ip address>:/boot
```



If the `/boot` mounting point does not exist yet, please see [how to create a mounting point](#)

- Reboot the board

```
Board $> cd /boot; sync; systemctl reboot
```

Note that this use case modifies the configuration file in the Linux kernel build directory, not in the Linux kernel source directory: this is a temporary modification useful for a prototyping.

- To make this temporary modification permanent, it must be saved in a configuration fragment file (fragment-\*.config) based on **fragment.cfg** file, and the Linux kernel configuration/compilation steps must be re-executed: **bitbake <name of kernel recipe>**.

## 4 References

- [Wikipedia Menuconfig](#)



Board support package

Software development kit (A programming package that enables a programmer to develop applications for a specific platform.)

## Menuconfig or how to configure kernel

Stable: 31.01.2020 - 13:23 / Revision: 31.01.2020 - 13:16

Template:ArticleMainWriter Template:ArticleApprovedVersion

### Contents

1 Linux configuration genericity .....	13
2 Menuconfig and Developer Package .....	15
3 Menuconfig and Distribution Package .....	17
4 References .....	17

## 1 Linux configuration genericity

The process of building a kernel has two parts: configuring the kernel options and building the source with those options.

The Linux<sup>®</sup> kernel configuration is found in the generated file: `.config`.

`.config` is the result of configuring task which is processing platform `defconfig` and fragment files if any.

For OpenSTLinux distribution the `defconfig` is located into the kernel source code and fragments into `stm32mp` BSP layer :

- `arch/arm/configs/multi_v7_defconfig`

Every new kernel version brings a bunch of new options, we do not want to back port them into a specific `defconfig` file each time the kernel releases, so we use the same `defconfig` file based on ARM SoC v7 architecture.

STM32MP1 specificities are managed with fragments `config` files.

- `meta-st/meta-st-stm32mp/recipes-kernel/linux/linux-stm32mp/<kernel version>/fragment-*.config`

`.config` result is located in the build folder:

- `build-openstlinuxweston-stm32mp1/tmp-glibc/work/stm32mp1-openstlinux_weston-linux-gnueabi/linux-stm32mp/4.14-48/linux-stm32mp1-standard-build/.config`

**To modify the kernel options, it is not recommended to edit this file directly.**

- A user runs either a text-mode :

```
PC $> make config
starts a character based question and answer session (Figure 1)
```

```
PC $> make menuconfig
starts a terminal-oriented configuration tool (using ncurses) (Figure 2)
The ncurses text version is more popular and is run with the make menuconfig option.
```

```
[greg@shamp linux-2.5]$ make config
make[1]: `scripts/kconfig/conf' is up to date.
./scripts/kconfig/conf arch/i386/Kconfig
#
# using defaults found in .config
#
*
* Linux Kernel Configuration
*
*
* Code maturity level options
*
Prompt for development and/or incomplete code/drivers (EXPERIMENTAL) [Y/n/?] █
```

Figure 1. Configuring the kernel with make config

**Wikipedia**

**Menuconfig**<sup>[1]</sup> also explains how to "navigate" within the configuration menu, and highlights main key strokes.

- or a graphical kernel configurator :

**PC \$>** make xconfig starts a X based configuration tool (Figure 3)



Figure 2. Make menuconfig makes it easier to back up and correct mistakes

Ultimately these configuration tools edit the .config file.

An option indicates either some driver is built into the kernel ("=y") or will be built as a module ("=m") or is not selected.

The unselected state can either be indicated by a line starting with "#" (e.g. "# CONFIG\_SCSI is not set") or by the absence of the relevant line from the .config file.

SCSI subsystem (which actually selects the SCSI mid level driver) follow. Only one of these should appear in an actual .config file:

```
CONFIG_SCSI=y
CONFIG_SCSI=m
# CONFIG_SCSI is not set
```

The 3 states of the main selection option for the




Figure 3. The Qt-Based make xconfig

## 2 Menuconfig and Developer Package

For this use case, the prerequisite is that OpenSTLinux SDK has been installed and configured.

To verify if your cross-compilation environment has been put in place correctly, run the following command:

```
PC $> set | grep CROSS
CROSS_COMPILE=arm-openstlinux_weston-linux-gnueabi-
```

For more details, refer to [<Linux kernel installation directory>/README.HOW\\_TO.txt](#) helper file (the latest version of this helper file is also available in this user guide: [README.HOW\\_TO.txt](#)).

- Go to the [<Linux kernel build directory>](#)

```
PC $> cd <Linux kernel build directory>
```

- Save initial configuration (to identify later configuration updates)

```
PC $> make arch=ARM savedefconfig
Result is stored in defconfig file
PC $> cp defconfig defconfig.old
```

- Start the Linux kernel configuration menu

```
PC $> make arch=ARM menuconfig
```

- Navigate forwards or backwards directly between feature
  - un/select, modify feature(s) you want
  - When the configuration is OK : exit and save the new configuration

useful keys to know:

**enter**: enter in config subdirectory

**space**: hit several times to either select [\*], select in module [m] or unselect [ ]

**/:** to search for a keyword, this is useful to navigate in tree

**?:** to have more information on selected line

- Compare the old and new config files after operating modifications with menuconfig

```
PC $> make arch=ARM savedefconfig
```

Retrieve configuration updates by comparing the new defconfig and the old one

```
PC $> meld defconfig defconfig.old
```

- Cross-compile the Linux kernel (please check the load address in the *README.HOW\_TO.txt* helper file)

```
PC $> make arch=ARM uImage LOADADDR=<loadaddr of kernel>
```

```
PC $> cp arch/arm/boot/uImage install_artifact/boot/
```

- Update the Linux kernel image on board

```
PC $> scp install_artifact/boot/uImage root@<board ip address>:/boot/
```



If the */boot* mounting point doesn't exist yet, please see [how to create a mounting point](#)

- Reboot the board

```
Board $> cd /boot; sync; systemctl reboot
```

Note that this use case modifies the configuration file in the Linux kernel build directory, not in the Linux kernel source directory: this is a temporary modification useful for a prototyping.

- To make this temporary modification permanent, the delta between defconfig and defconfig.old must be saved in a configuration fragment file (fragment-\*.config) based on fragment.cfg file, and the Linux kernel configuration /compilation steps must be re-executed (as explained in the *README.HOW\_TO.txt* helper file).

## 3 Menuconfig and Distribution Package

- Start the Linux kernel configuration menu

```
PC $> bitbake virtual/kernel -c menuconfig
```

- Navigate forwards or backwards directly between feature
  - un/select, modify feature(s) you want
  - When the configuration is OK : exit and save the new configuration

useful keys to know:

**enter**: enter in config subdirectory

**space**: hit several times to either select **[\*]**, select in module **[m]** or unselect **[ ]**

**/:** to search for a keyword, this is usefull to navigate in tree

**?:** to have more information on selected line

- Cross-compile the Linux kernel

```
PC $> bitbake virtual/kernel
```

- Update the Linux kernel image on board

```
PC $> scp <build dir>/tmp-glibc/deploy/images/<machine name>/uImage root@<board ip address>:/boot
```



If the `/boot` mounting point does not exist yet, please see [how to create a mounting point](#)

- Reboot the board

```
Board $> cd /boot; sync; systemctl reboot
```

Note that this use case modifies the configuration file in the Linux kernel build directory, not in the Linux kernel source directory: this is a temporary modification useful for a prototyping.

- To make this temporary modification permanent, it must be saved in a configuration fragment file (fragment-\*.config) based on **fragment.cfg** file, and the Linux kernel configuration/compilation steps must be re-executed: **bitbake <name of kernel recipe>**.

## 4 References

- [Wikipedia Menuconfig](#)



Board support package

Software development kit (A programming package that enables a programmer to develop applications for a specific platform.)

# Menuconfig or how to configure kernel

Stable: 24.01.2020 - 10:14 / Revision: 24.01.2020 - 10:12

Template:ArticleMainWriter Template:ArticleApprovedVersion

## Contents

1 Linux configuration genericity .....	18
2 Menuconfig and Developer Package .....	20
3 Menuconfig and Distribution Package .....	22
4 References .....	22

## 1 Linux configuration genericity

The process of building a kernel has two parts: configuring the kernel options and building the source with those options.

The Linux<sup>®</sup> kernel configuration is found in the generated file: `.config`.

`.config` is the result of configuring task which is processing platform `defconfig` and fragment files if any.

For OpenSTLinux distribution the `defconfig` is located into the kernel source code and fragments into `stm32mp` BSP layer :

- `arch/arm/configs/multi_v7_defconfig`

Every new kernel version brings a bunch of new options, we do not want to back port them into a specific `defconfig` file each time the kernel releases, so we use the same `defconfig` file based on ARM SoC v7 architecture.

STM32MP1 specificities are managed with fragments `config` files.

- `meta-st/meta-st-stm32mp/recipes-kernel/linux/linux-stm32mp/<kernel version>/fragment-*.config`

`.config` result is located in the build folder:

- `build-openstlinuxweston-stm32mp1/tmp-glibc/work/stm32mp1-openstlinux_weston-linux-gnueabi/linux-stm32mp/4.14-48/linux-stm32mp1-standard-build/.config`

**To modify the kernel options, it is not recommended to edit this file directly.**

- A user runs either a text-mode :

```
PC $> make config
starts a character based question and answer session (Figure 1)
```

```
PC $> make menuconfig
starts a terminal-oriented configuration tool (using ncurses) (Figure 2)
The ncurses text version is more popular and is run with the make menuconfig option.
```

```
[greg@shamp linux-2.5]$ make config
make[1]: `scripts/kconfig/conf' is up to date.
./scripts/kconfig/conf arch/i386/Kconfig
#
# using defaults found in .config
#
*
* Linux Kernel Configuration
*
*
* Code maturity level options
*
Prompt for development and/or incomplete code/drivers (EXPERIMENTAL) [Y/n/?]
```

Figure 1. Configuring the kernel with make config

**Wikipedia**

**Menuconfig**<sup>[1]</sup> also explains how to "navigate" within the configuration menu, and highlights main key strokes.

- or a graphical kernel configurator :

**PC \$>** make xconfig starts a X based configuration tool (Figure 3)




Figure 2. Make menuconfig makes it easier to back up and correct mistakes

Ultimately these configuration tools edit the .config file.

An option indicates either some driver is built into the kernel ("=y") or will be built as a module ("=m") or is not selected.

The unselected state can either be indicated by a line starting with "#" (e.g. "# CONFIG\_SCSI is not set") or by the absence of the relevant line from the .config file.

SCSI subsystem (which actually selects the SCSI mid level driver) follow. Only one of these should appear in an actual .config file:

```
CONFIG_SCSI=y
CONFIG_SCSI=m
# CONFIG_SCSI is not set
```

The 3 states of the main selection option for the




Figure 3. The Qt-Based make xconfig

## 2 Menuconfig and Developer Package

For this use case, the prerequisite is that OpenSTLinux SDK has been installed and configured.

To verify if your cross-compilation environment has been put in place correctly, run the following command:

```
PC $> set | grep CROSS
CROSS_COMPILE=arm-openstlinux_weston-linux-gnueabi-
```

For more details, refer to [<Linux kernel installation directory>/README.HOW\\_TO.txt](#) helper file (the latest version of this helper file is also available in this user guide: [README.HOW\\_TO.txt](#)).

- Go to the [<Linux kernel build directory>](#)

```
PC $> cd <Linux kernel build directory>
```

- Save initial configuration (to identify later configuration updates)

```
PC $> make arch=ARM savedefconfig
Result is stored in defconfig file
PC $> cp defconfig defconfig.old
```

- Start the Linux kernel configuration menu

```
PC $> make arch=ARM menuconfig
```

- Navigate forwards or backwards directly between feature
  - un/select, modify feature(s) you want
  - When the configuration is OK : exit and save the new configuration

useful keys to know:

**enter**: enter in config subdirectory

**space**: hit several times to either select [\*], select in module [m] or unselect [ ]

**/:** to search for a keyword, this is usefull to navigate in tree

**?:** to have more information on selected line

- Compare the old and new config files after operating modifications with menuconfig

```
PC $> make arch=ARM savedefconfig
```

Retrieve configuration updates by comparing the new defconfig and the old one

```
PC $> meld defconfig defconfig.old
```

- Cross-compile the Linux kernel (please check the load address in the *README.HOW\_TO.txt* helper file)

```
PC $> make arch=ARM uImage LOADADDR=<loadaddr of kernel>
```

```
PC $> cp arch/arm/boot/uImage install_artifact/boot/
```

- Update the Linux kernel image on board

```
PC $> scp install_artifact/boot/uImage root@<board ip address>:/boot/
```



If the */boot* mounting point doesn't exist yet, please see [how to create a mounting point](#)

- Reboot the board

```
Board $> cd /boot; sync; systemctl reboot
```

Note that this use case modifies the configuration file in the Linux kernel build directory, not in the Linux kernel source directory: this is a temporary modification useful for a prototyping.

- To make this temporary modification permanent, the delta between defconfig and defconfig.old must be saved in a configuration fragment file (fragment-\*.config) based on fragment.cfg file, and the Linux kernel configuration /compilation steps must be re-executed (as explained in the *README.HOW\_TO.txt* helper file).

## 3 Menuconfig and Distribution Package

- Start the Linux kernel configuration menu

```
PC $> bitbake virtual/kernel -c menuconfig
```

- Navigate forwards or backwards directly between feature
  - un/select, modify feature(s) you want
  - When the configuration is OK : exit and save the new configuration

useful keys to know:

**enter**: enter in config subdirectory

**space**: hit several times to either select **[\*]**, select in module **[m]** or unselect **[ ]**

**/:** to search for a keyword, this is usefull to navigate in tree

**?:** to have more information on selected line

- Cross-compile the Linux kernel

```
PC $> bitbake virtual/kernel
```

- Update the Linux kernel image on board

```
PC $> scp <build dir>/tmp-glibc/deploy/images/<machine name>/uImage root@<board ip address>:/boot
```



If the `/boot` mounting point does not exist yet, please see [how to create a mounting point](#)

- Reboot the board

```
Board $> cd /boot; sync; systemctl reboot
```

Note that this use case modifies the configuration file in the Linux kernel build directory, not in the Linux kernel source directory: this is a temporary modification useful for a prototyping.

- To make this temporary modification permanent, it must be saved in a configuration fragment file (fragment-\*.config) based on **fragment.cfg** file, and the Linux kernel configuration/compilation steps must be re-executed: **bitbake <name of kernel recipe>**.

## 4 References

- [Wikipedia Menuconfig](#)



Menuconfig or how to configure kernel

---

Board support package

Software development kit (A programming package that enables a programmer to develop applications for a specific platform.)