



Networking overview



Networking overview

Stable: 11.02.2019 - 11:21 / Revision: 17.01.2019 - 08:56

A [quality version](#) of this page, [accepted](#) on *11 February 2019*, was based off this revision.

[Template:ArticleMainWriter](#) [Template:ArticleApprovedVersion](#)


SUMMARY

This article explains how net devices are mapped to the Linux [Template:Sup](#) kernel netdevice stack.

1 Purpose

This article introduces the Linux[®] kernel netdevice. Its purpose is to provide to newcomers some first insights regarding networking. The other articles referenced in this page provide detailed information about each component connected to netdevice.

2 System overview



On STM32MP1 Series, the netdevice stack is used for two purposes: CAN and Ethernet. A more detailed block diagram of each interface is available in dedicated pages: [CAN](#) and [Ethernet](#).

LinuxTemplate:Sup community offers several links to help understanding the netdevice stack:

- Kernel networking flow ^[1],
- Kernel networking documentation^[2]

3 References

- ^[1], Kernel networking flow
- ^[2], Kernel networking documentation



Networking overview

Controller Area Network (robust bus mainly used for automotive applications)