



STM32MP1 Developer Package - Linux kernel



STM32MP1 Developer Package - Linux kernel

Stable: 11.03.2020 - 15:22 / Revision: 11.03.2020 - 13:53

This article provides the following information:

- How to download and install the **latest** Linux kernel for the STM32 microprocessor Series used
- Where to find the associated release note
- Where to find the previous releases (archives)



To use this package efficiently, please read the Developer Package article relative to your STM32 microprocessors Series: [Category:Developer Package](#)

1 STM32MP15-Ecosystem-v1.1.0 release

- The STM32MP1 Linux kernel is delivered through a tarball file named :
 - **en.SOURCES-kernel-stm32mp1-openstlinux-4.19-thud-mp1-19-10-09.tar.xz** for STM32MP157C-EV1 and STM32MP157X-DKX boards
- Download and install the STM32MP1 Linux kernel

By downloading this software package, you agree to be bound to the terms of the [software license agreement \(SLA\)](#). The detailed content licenses can be found [here](#).

STM32MP1 Developer Package Linux kernel - STM32MP15-Ecosystem-v1.1.0 release	
Down load	You need to be logged on to my.st.com before accessing the following link en.SOURCES-kernel-stm32mp1-openstlinux-4.19-thud-mp1-19-10-09.tar.xz
Install ation	<ul style="list-style-type: none">• Go to the host PC directory in which you want to install the Developer Package (<Developer Package installation directory>); if you follow the proposition to organize the working directory, this means:<pre>\$ cd <working directory path>/Developer-Package</pre>• Download the tarball file in this directory• Uncompress the tarball file to get the Linux kernel (Linux kernel source code, ST patches, ST configuration fragments...):<pre>\$ tar xvf en.SOURCES-kernel-stm32mp1-openstlinux-4.19-thud-mp1-19-10-09.tar.xz</pre><pre>\$ cd stm32mp1-openstlinux-4.19-thud-mp1-19-10-09/sources/arm-openstlinux_weston-linux-gnueabi/linux-stm32mp-4.19-r0/</pre><pre>\$ tar xvf linux-4.19.49.tar.xz</pre>



Release note	<p>Details of the content of the Linux kernel are available in the associated STM32MP15 OpenSTLinux release note.</p> <p>If you are interested in older releases, please have a look into the section Archives.</p>
--------------	--

- The **Linux kernel installation directory** is in the `<Developer Package installation directory>/stm32mp1-openstlinux-4.19-thud-mp1-19-10-09/sources/arm-openstlinux_weston-linux-gnueabi` directory, and is named `linux-stm32mp-<kernel version>`:

<pre> linux-stm32mp-4.19-r0 ├── [*].patch ├── fragment-[*].config ├── linux-4.19.49 ├── linux-4.19.49.tar.xz ├── README.HOW_TO.txt └── series </pre>	<p>Linux kernel installation directory ST patches to apply during the Linux kernel preparation (see next chapter)</p> <p>ST configuration fragments to apply during the Linux kernel configuration (see next chapter)</p> <p>Linux kernel source code directory Tarball file of the Linux kernel source code</p> <p>Helper file for Linux kernel management: reference for Linux kernel build</p> <p>List of all ST patches to apply</p>
--	---

2 Archives

2.1 STM32MP15-Ecosystem-v1.0.0 release

- The STM32MP1 Linux kernel is delivered through a tarball file named :
 - en.SOURCES-kernel-stm32mp1-openstlinux-4.19-thud-mp1-19-02-20.tar.xz** for STM32MP157C-EV1 and STM32MP157X-DKX boards
- Download and install the STM32MP1 Linux kernel

By downloading this software package, you agree to be bound to the terms of the [software license agreement \(SLA\)](#). The detailed content licenses can be found [here](#).

STM32MP1 Developer Package Linux kernel - STM32MP15-Ecosystem-v1.0.0 release	
Download	<p>You need to be logged on to my.st.com before accessing the following link en.SOURCES-kernel-stm32mp1-openstlinux-4.19-thud-mp1-19-02-20.tar.xz</p>
	<ul style="list-style-type: none"> Go to the host PC directory in which you want to install the Developer Package (<code><Developer Package installation directory></code>); if you follow the proposition to organize the working directory, this means: <div style="border: 1px dashed black; padding: 5px; margin: 10px 0;"> <pre>\$ cd <working directory path>/Developer-Package</pre> </div> Download the tarball file in this directory



STM32MP1 Developer Package Linux kernel - STM32MP15-Ecosystem-v1.0.0 release	
Installation	<ul style="list-style-type: none">Uncompress the tarball file to get the Linux kernel (Linux kernel source code, ST patches, ST configuration fragments...): <pre>\$ tar xvf en.SOURCES-kernel-stm32mp1-openstlinux-4.19-thud-mp1-19-02-20.tar.xz \$ cd stm32mp1-openstlinux-4.19-thud-mp1-19-02-20/sources/arm-openstlinux_weston-linux-gnueabi/linux-stm32mp-4.19-r0/ \$ tar xvf linux-4.19.9.tar.xz</pre>
Release note	Details of the content of the Linux kernel are available in the associated STM32MP15 OpenSTLinux release note .

- The **Linux kernel installation directory** is in the *<Developer Package installation directory>/stm32mp1-openstlinux-4.19-thud-mp1-19-02-20/sources/arm-openstlinux_weston-linux-gnueabi* directory, and is named *linux-stm32mp-<kernel version>*:

<pre>linux-stm32mp-4.19-r0 ├─ [*].patch ├─ fragment-[*].config ├─ linux-4.19.9 ├─ linux-4.19.9.tar.xz ├─ README.HOW_TO.txt └─ series</pre>	<p>Linux kernel installation directory ST patches to apply during the Linux kernel preparation (see next chapter)</p> <p>ST configuration fragments to apply during the Linux kernel configuration (see next chapter)</p> <p>Linux kernel source code directory</p> <p>Tarball file of the Linux kernel source code</p> <p>Helper file for Linux kernel management: reference for Linux kernel build</p> <p>List of all ST patches to apply</p>
--	--