



PC prerequisites



Contents

1. PC prerequisites	36
2. ADB	91
3. Git	25
4. ST-LINK	47
5. STM32CubeMX	58
6. STM32CubeProgrammer	69
7. Which Package better suits your needs	80



A quality version of this page, approved on 17 November 2020, was based off this revision.

Information

Recommended setup: Native Linux PC

Contents

1 Purpose	37
2 Recommended PC configurations	38
3 Linux PC	39
3.1 Check Internet access	39
3.2 Install extra packages	40
3.2.1 Install extra packages for Android	41
3.3 Additional configurations	42
3.4 Setup <i>Git</i> user information	43
4 Windows PC	44
4.1 Virtual Machine System	44
4.1.1 Virtual Machine installation	44
4.1.2 Download the Ubuntu image for the virtual machine	44
4.1.3 Launch of Ubuntu image	45
4.2 WSL2 (experimental)	46
4.3 References	46



1 Purpose

This article explains and describes the hardware configuration required to be able to activate and run the STM32 MPU platforms.



2 Recommended PC configurations

The PC requirements depend on the [Package](#) you want to use.

The table below guides through the selection and configuration of the host PC environment according the targeted [Package](#):

Host Environment	Starter Package	Developer Package	Distribution Package
Windows (64 bits) Tested with Windows7 and Windows10 Preferred version Windows 10	native	Virtual Machine	Virtual Machine
Linux (64 bits) Tested with Ubuntu 18.04 and 20.04	native	native + additional packages (see Linux PC chapter)	native + additional packages (see Linux PC chapter)

There are no absolute minimal requirements regarding the PC hardware configuration, however ST recommends to meet or exceed the following hardware configurations when using *Developer Package* or *Distribution Package*.

The table below correspond to the minimal validated configuration:

Hardware item	Minimal validated configuration	Comments / Recommendations
CPU	core i5-2540M @ 2.6GHz 2 cores (4 threads) 3MB cache	64 bits instruction set is mandatory 8 cores/threads or more is a good config moreover for <i>Developer Package</i> and <i>Distribution Package</i> .
RAM	8GB	16GB or more is recommended especially for <i>Virtual Machine</i> setup , <i>Developer Package</i> and <i>Distribution Package</i> .
Hard Drive	320GB	1TB is probably a better config when using <i>Distribution Package</i>



3 Linux PC

A Linux PC with **Ubuntu 18.04** is the recommended setup. Other Ubuntu revisions should also be supported, please refer to Yocto Manual^[1].

i Information

ecosystem release v2.1.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 20.04 LTS).

i Information

ecosystem release v2.0.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 16.04 LTS).

3.1 Check Internet access

- **An Internet access through http and https protocols must be provided.**

Required for *Developer Package* and *Distribution Package* at least.

The command below allows to check for Internet access through http/https protocols:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```

If a 'OK' message is returned, the network is well configured. In such case, skip the rest of this section and jump to next one (Install extra packages).

Any other situation likely indicates the need for a proxy for http/https protocols.

The best solution to set a proxy for http/https protocols is via the shell variables `http_proxy` and `https_proxy`:

```
PC $> export http_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
PC $> export https_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
```

Because your password may contains "special characters" you need to translate your password into ASCII hexacode. By this way you can translate `<MyProxyPassword>` into hexacode by using this command :

```
PC $> echo -n "<MyProxyPassword>" | od -A n -t x1 -w128 | head -1 | tr " " "%"
```

Check again the Internet access with command:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```



- Internet access for *sudo* commands

Required for *Distribution Package*.

sudo commands are executed in the *root* user environment; by default, no Internet proxy settings are applied for *root* user. *Root* user should be able to browse Internet, after creation of an alias passing the proxy settings on *sudo* command:

```
PC $> alias sudo='sudo http_proxy=$http_proxy'
```

Check that the *sudo* commands is successful (requires Internet access):

```
PC $> sudo apt-get update
```

- Internet over *git://*, *ssh://* and others specifics protocols

Required for *Distribution Package*.

In addition to http/https protocols (used in 90% of the Internet traffic), some other protocols like *git://* or *ssh://* may be required.

For example in the context of the *Distribution Package*, some "git fetch" commands could require "git://" protocols".

In order to support these protocols through a proxy, the best way is to directly setup the proxy in the `$HOME/.gitconfig` file (core.gitproxy) and use a tool like *cockscrew*^[2] in order to tunnel the *git://* flow into the http flow:

```
PC $> sudo apt-get update
PC $> sudo apt-get install cockscrew

PC $> git config --replace-all --global core.gitproxy "$HOME/bin/git-proxy.sh"
PC $> git config --add --global core.gitproxy "none for <MyPrivateNetworkDomain>"
(optionnal and for example .st.com, localhost, ...)
PC $> echo 'exec cockscrew <MyProxyServerUrl> <MyProxyPort> $* $HOME/.git-proxy.auth' >
$HOME/bin/git-proxy.sh
PC $> chmod 700 $HOME/bin/git-proxy.sh
PC $> echo '<MyProxyLogin>:<MyProxyPassword>' > $HOME/.git-proxy.auth
PC $> chmod 600 $HOME/.git-proxy.auth
```

Here is a command to test this proxy settings:

```
PC $> git ls-remote git://git.openembedded.org/openembedded-core > /dev/null && echo OK
|| echo KO
```

The command should return 'OK', else proxy settings are wrong.

3.2 Install extra packages

Required for *Developer Package* and *Distribution Package*.

In order to do basic development tasks, basic cross-compilation (via *Developer Package*) or more complex cross-compilation as OpenEmbedded does (via *Distribution Package*), some extra Ubuntu packages should be installed:

- Packages required by OpenEmbedded/Yocto (details here):



```
PC $> sudo apt-get update
PC $> sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib build-essential chrpath socat cpio python3 python3-pip python3-pexpect xz-utils debianutils iputils-ping python3-git python3-jinja2 libegl1-mesa libsdl1.2-dev pylint3 pylint xterm
PC $> sudo apt-get install make xsltproc docbook-utils fop dblatex xmlto
```

- Packages needed for some "Developer Package" use cases:

```
PC $> sudo apt-get install libncurses5-dev libncursesw5-dev libssl-dev linux-headers-generic u-boot-tools device-tree-compiler bison flex g++ libyaml-dev
```

- Package for repo (used to download the "Distribution Package" source code):

Please follow official instructions to install [repo](#)
For Ubuntu 16.04 you should use the legacy repo [old-repo-python2](#) chapter

- Some useful tools:

```
PC $> sudo apt-get install coreutils bsdmainutils sed curl bc lrzsz corkscrew cvs subversion mercurial nfs-common nfs-kernel-server libarchive-zip-perl dos2unix texi2html diffstat libxml2-utils
```

You can also install a Java Runtime Engine, this is required for [STM32CubeMX](#) and [STM32CubeProgrammer](#)

```
PC $> sudo apt-get install default-jre
```

3.2.1 Install extra packages for Android

Below information is related to the Android™ distribution

Before downloading and building the STM32MPU distribution for Android™, make sure your system meets the following requirements:

- A 64-bit Linux® environment.
- At least 150 Gbytes of free disk space. If you conduct multiple builds, even more space is required.
- At least 8 Gbytes of RAM/swap. If you are running Linux on a virtual machine, at least 16 Gbytes of RAM/swap are required.

For more details, refer to the [requirements page](#) of the AOSP website.

Use the following commands to install the packages required to build an environment for Android (Distribution Package), after having installed the required packages [listed on Android website](#):



```
sudo apt-get update
sudo apt-get install chrpath curl libxml2-utils gdisk pv python-pycryptopp python-crypto autotools-dev automake libusb-1.0-0-dev
```




To ensure USB communication (with ADB) between the host and the device, see [ADB § Device Connection](#).

To run Android-provided tests (CTS and VTS), see [Android Platform Testing](#).

At this stage: Your environment is ready for Android build, debug and test.

3.3 Additional configurations

- Allow up to 16 partitions per mmc

By default, on Linux system, a maximum of 8 partitions are allowed on mmc. All Packages (Starter Package, ...) need more than 10 partitons for the storage device. In order to extend the number of partitions per device to 16, the following options must be added to modprobe:

```
PC $> echo 'options mmc_block perdev_minors=16' > /tmp/mmc_block.conf
PC $> sudo mv /tmp/mmc_block.conf /etc/modprobe.d/mmc_block.conf
```

- Check for *locale* setup

Required for *Distribution Package*.

The *locale* setting is used by some applications/commands (including by *Distribution Package* applications/commands). Verify that the *locale* settings are as follows:

```
PC $> locale
LANG=en-US.UTF-8
```

In case the *locale* command returns a different configuration than the one shown above, it must be reconfigured as follows:

```
PC $> sudo update-locale LANG=en_US.UTF-8
```

- Add user in basics groups

The *user* login should belong to the basic Linux groups such as **disk**, **tty**, **dialout** or **plugdev**

Use the command *groups* to list groups for the current user:

```
PC $> groups
```

If needed add *user* to the missing *<groups>*:

```
PC $> sudo adduser $USER <group>
```

Then **reboot** the PC.



3.4 Setup *Git* user information

Required for *Developer Package* and *Distribution Package*.

The User Information is needed by git^[3] in case *commit* and/or *push* commands are being used :

```
PC $> git config --global user.name "Your Name"  
PC $> git config --global user.email "you@example.com"
```



4 Windows PC

Starter Package may run on Windows.

Developer Package and *Distribution Package* require a Linux environment.

Warning

ST solutions, while reportedly functional when running on a Linux Virtual machine, are only validated for Linux native setups ...

There are several ways to run Linux system on top of a Windows host PC, ST recommends to use a Virtual Machine System:

1. Install a virtual machine such as VMWare ^[4]
2. Setup a **64 bits** Ubuntu image compatible with your virtual machine

ST, in an experimental way, has also run *Developer Package* and *Distribution Package* on a WSL2 (Windows Subsystem for Linux 2); see [WSL2](#) chapter.

4.1 Virtual Machine System

4.1.1 Virtual Machine installation

ST has selected VMWare as Linux virtual machine solution.

VMWare is a commercial company specialized in virtualization solutions. The available solutions to support a virtual Linux machine on a Windows PC are:

- VMWare Workstation Player (paid solution) for commercial use (download here ^[5])
- VMWare Workstation Player (free solution) for home use (download here ^[6])


Please proceed with the installation of the virtual machine.

Before running the virtual machine, make sure the virtualization is activated in the BIOS (it should be activated by default for any retail PC).

4.1.2 Download the Ubuntu image for the virtual machine

The "osboxes.org" ^[7] website provides virtual machine images compatible with VMWare(*.vmdk).

ecosystem release v2.1.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 20.04 (64bits).**

ecosystem release v2.0.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 16.04 (64bits).**

Download the 64 bits Ubuntu image available at ^[8] and:

1. Unzip the downloaded file
2. In VMware create a virtual machine using the Ubuntu virtual disk downloaded from osboxes.org.

The recommended usage is to dedicate, at least, half of the host machine to the virtual machine:



- CPU: 2 cores at least,
- RAM: 6 Gbytes or more is a good choice (the more RAM allocated to Virtual Machine the better - the RAM allocated to Virtual Machine must be 4GB minimum),
- Network: NAT is good and an easy way to benefit form a network connection within the virtual machine.

Virutal size of virtual disk downloaded from osboxes.org is about 500GB. Even if the real size of the file of the virtual disk is less at beginning, the size could growth up to 500GB over compiling distribution package or development package.

Information

For VMware, you need first to create a default virtual machine then add the `.vmdk` file, previously downloaded.

Please refer to the [VMwarePlayer screenshot tutorial](#).

4.1.3 Launch of Ubuntu image

Warning

For "AZERTY" keyboard users:

The default keyboard configuration is "QWERTY".

In order to configure the keyboard for "AZERTY", start by opening a session (take care that the keyboard layout is QWERTY).

TIP: the password for the default user "*osboxes.org*" is "*osboxes.org*".

TIP: the '.' character is obtained by clicking '.' on an AZERTY keyboard configured in QWERTY.

Once the session is opened, click the 'En' icon on top/right of the screen, select the French ('Fr') keyboard layout and move it to the first position in the list.

Optionally the 'En' keyboard can be completely removed. If the 'Fr' option is not present, it can be added with the 'Text entry setting' menu.

Default **Credentials** of the Ubuntu are set to "**osboxes.org**" for both login and password.

Warning

Adjust screen resolution:

The (default) resolution used by the virtual machine is 800x600 (smallest available). It is not automatically adjusted to the display resolution. In order to adjust the resolution, click the "settings" icon ('toothed wheel' on top/right of the screen), then "system settings ..." > "display" and select the appropriate resolution for the display (do not to forget to click the "Apply" button on bottom/left of the "Screen Resolution Setting" window).

For a better experience with the VMware virtual machine, install "vmware-tools" in order to be able to use the clipboard to drag-and-drop and copy/paste files between VMware and Windows. A step-by-step installation procedure of **vmware-tools** is available in the document: [PreRequisite-Vmware-tools.pdf](#)

The virtual machine is up and running!

The Ubuntu setup must be finalized according recommendations provided in [Linux PC chapter](#)

Warning

USB connection's speed:



USB connection is requested for accessing STLink (debugger and serial port) and by STM32CubeProgrammer. The speed of the USB connection between Linux running in the virtual machine and the external USB devices can be severely impacted by:

- the virtual machine USB setup;
- the USB controller in the host PC;
- the USB device connected to host PC;
- any USB hub between the USB host and the USB device.

If the speed of your USB connection is too low, we suggest to:

- try different USB configurations of the virtual machine;
- connect the USB device directly on the host USB port (without any USB hub);
- try connecting the USB device to another USB port of the host (some PC have different USB controller on different USB port).

4.2 WSL2 (experimental)

Even if STMicroelectronics strongly recommends to use a Linux® environment, the *Developer Package* and *Distribution Package* works in WSL2 (Windows Sub-system Linux 2) environment. WSL is a feature provided by **Windows 10®**. ST has run unsuccessfully *Developer Package* and *Distribution Package* on WSL but successfully on WSL2. WSL2 is available on Windows 10® since build 18917.

WSL 2 is a new version of the architecture that powers the Windows Subsystem for Linux to run ELF64 Linux binaries on Windows (more details on aka.ms/wsl2).

- WSL2 - Installation :
 - To install WSL2 please read this webpage: <https://docs.microsoft.com/fr-fr/windows/wsl/wsl2-install>
 - Once WSL2 installed, jump to chapter #Linux_PC to make your WSL2 ready to run *Developer Package* and/or *Distribution Package*.
- WSL2 - Limitations :
 - WSL2 up to now (09/2019) does not support hardware such as USB devices, serial, ... (more details).
This means, STM32CubeProgrammer should be used through native Windows
 - WSL2 files are not browsable from Windows native file explorer.
To share files between WSL2 and Windows, the preferred way is to use the mount point `/mnt/c` from WSL2 and do copies.
- WSL2 - Tips :
 - Launch graphical application : On wiki.ubuntu.com the page on WSL contains a chapter Running Graphical Applications.

4.3 References

- Supported Linux Distributionsl
- [https://en.wikipedia.org/wiki/Corkscrew_\(program\)](https://en.wikipedia.org/wiki/Corkscrew_(program))
- Git
- <http://vmware.com>
- https://my.vmware.com/en/web/vmware/free#desktop_end_user_computing/vmware_workstation_player/15_0
- <https://www.vmware.com/products/workstation-player/workstation-player-evaluation.html>
- <http://osboxes.org>
- <https://www.osboxes.org/ubuntu/#ubuntu-1804-vmware>



Linux® is a registered trademark of Linus Torvalds.

Microprocessor Unit

Central processing unit

Random Access Memory (Early computer memories generally had serial access. Memories where any given address can be accessed when desired were then called "random access" to distinguish them from the memories where contents can only be accessed in a fixed order. The term is used today for volatile random-access semiconductor memories.)

Android Open Source Project

Android debug bridge (Android specific)

Compatibility Test Suite (Android specific) or Clear to send (in UART context)

Vendor Test Suite (Android specific)

ST in-circuit debugger and programmer for the STM8 and STM32 microcontroller families (See ST-LINK for more details)

Stable: 15.02.2021 - 12:33 / Revision: 12.02.2021 - 08:25

Information

Recommended setup: Native Linux PC

Contents

1 Purpose	15
2 Recommended PC configurations	16
3 Linux PC	17
3.1 Check Internet access	17
3.2 Install extra packages	18
3.2.1 Install extra packages for Android	19
3.3 Additional configurations	20
3.4 Setup <i>Git</i> user information	21
4 Windows PC	22
4.1 Virtual Machine System	22
4.1.1 Virtual Machine installation	22
4.1.2 Download the Ubuntu image for the virtual machine	22
4.1.3 Launch of Ubuntu image	23
4.2 WSL2 (experimental)	24
4.3 References	24



1 Purpose

This article explains and describes the hardware configuration required to be able to activate and run the STM32 MPU platforms.



2 Recommended PC configurations

The PC requirements depend on the [Package](#) you want to use.

The table below guides through the selection and configuration of the host PC environment according the targeted [Package](#):

Host Environment	Starter Package	Developer Package	Distribution Package
Windows (64 bits) Tested with Windows7 and Windows10 Preferred version Windows 10	native	Virtual Machine	Virtual Machine
Linux (64 bits) Tested with Ubuntu 18.04 and 20.04	native	native + additional packages (see Linux PC chapter)	native + additional packages (see Linux PC chapter)

There are no absolute minimal requirements regarding the PC hardware configuration, however ST recommends to meet or exceed the following hardware configurations when using *Developer Package* or *Distribution Package*.

The table below correspond to the minimal validated configuration:

Hardware item	Minimal validated configuration	Comments / Recommendations
CPU	core i5-2540M @ 2.6GHz 2 cores (4 threads) 3MB cache	64 bits instruction set is mandatory 8 cores/threads or more is a good config moreover for <i>Developer Package</i> and <i>Distribution Package</i> .
RAM	8GB	16GB or more is recommended especially for <i>Virtual Machine</i> setup , <i>Developer Package</i> and <i>Distribution Package</i> .
Hard Drive	320GB	1TB is probably a better config when using <i>Distribution Package</i>



3 Linux PC

A Linux PC with **Ubuntu 18.04** is the recommended setup. Other Ubuntu revisions should also be supported, please refer to Yocto Manual^[1].

i Information

ecosystem release v2.1.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 20.04 LTS).

i Information

ecosystem release v2.0.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 16.04 LTS).

3.1 Check Internet access

- **An Internet access through http and https protocols must be provided.**

Required for *Developer Package* and *Distribution Package* at least.

The command below allows to check for Internet access through http/https protocols:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```

If a 'OK' message is returned, the network is well configured. In such case, skip the rest of this section and jump to next one (Install extra packages).

Any other situation likely indicates the need for a proxy for http/https protocols.

The best solution to set a proxy for http/https protocols is via the shell variables `http_proxy` and `https_proxy`:

```
PC $> export http_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
PC $> export https_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
```

Because your password may contains "special characters" you need to translate your password into ASCII hexacode. By this way you can translate `<MyProxyPassword>` into hexacode by using this command :

```
PC $> echo -n "<MyProxyPassword>" | od -A n -t x1 -w128 | head -1 | tr " " "%"
```

Check again the Internet access with command:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```



- Internet access for *sudo* commands

Required for *Distribution Package*.

sudo commands are executed in the *root* user environment; by default, no Internet proxy settings are applied for *root* user. *Root* user should be able to browse Internet, after creation of an alias passing the proxy settings on *sudo* command:

```
PC $> alias sudo='sudo http_proxy=$http_proxy'
```

Check that the *sudo* commands is successful (requires Internet access):

```
PC $> sudo apt-get update
```

- Internet over *git://*, *ssh://* and others specifics protocols

Required for *Distribution Package*.

In addition to http/https protocols (used in 90% of the Internet traffic), some other protocols like *git://* or *ssh://* may be required.

For example in the context of the *Distribution Package*, some "git fetch" commands could require "git://" protocols".

In order to support these protocols through a proxy, the best way is to directly setup the proxy in the `$HOME/.gitconfig` file (core.gitproxy) and use a tool like *cockscrew*^[2] in order to tunnel the *git://* flow into the http flow:

```
PC $> sudo apt-get update
PC $> sudo apt-get install cockscrew

PC $> git config --replace-all --global core.gitproxy "$HOME/bin/git-proxy.sh"
PC $> git config --add --global core.gitproxy "none for <MyPrivateNetworkDomain>"
(optionnal and for example .st.com, localhost, ...)
PC $> echo 'exec cockscrew <MyProxyServerUrl> <MyProxyPort> $* $HOME/.git-proxy.auth' >
$HOME/bin/git-proxy.sh
PC $> chmod 700 $HOME/bin/git-proxy.sh
PC $> echo '<MyProxyLogin>:<MyProxyPassword>' > $HOME/.git-proxy.auth
PC $> chmod 600 $HOME/.git-proxy.auth
```

Here is a command to test this proxy settings:

```
PC $> git ls-remote git://git.openembedded.org/openembedded-core > /dev/null && echo OK
|| echo KO
```

The command should return 'OK', else proxy settings are wrong.

3.2 Install extra packages

Required for *Developer Package* and *Distribution Package*.

In order to do basic development tasks, basic cross-compilation (via *Developer Package*) or more complex cross-compilation as OpenEmbedded does (via *Distribution Package*), some extra Ubuntu packages should be installed:

- Packages required by OpenEmbedded/Yocto (details here):



```
PC $> sudo apt-get update
PC $> sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib build-essential chrpath socat cpio python3 python3-pip python3-pexpect xz-utils debianutils iputils-ping python3-git python3-jinja2 libegl1-mesa libsdl1.2-dev pylint3 pylint xterm
PC $> sudo apt-get install make xsltproc docbook-utils fop dblatex xmlto
```

- Packages needed for some "Developer Package" use cases:

```
PC $> sudo apt-get install libncurses5-dev libncursesw5-dev libssl-dev linux-headers-generic u-boot-tools device-tree-compiler bison flex g++ libyaml-dev
```

- Package for repo (used to download the "Distribution Package" source code):

Please follow official instructions to install [repo](#)
For Ubuntu 16.04 you should use the legacy repo [old-repo-python2](#) chapter

- Some useful tools:

```
PC $> sudo apt-get install coreutils bsdmainutils sed curl bc lrzsz corkscrew cvs subversion mercurial nfs-common nfs-kernel-server libarchive-zip-perl dos2unix texi2html diffstat libxml2-utils
```

You can also install a Java Runtime Engine, this is required for [STM32CubeMX](#) and [STM32CubeProgrammer](#)

```
PC $> sudo apt-get install default-jre
```

3.2.1 Install extra packages for Android

Below information is related to the Android™ distribution

Before downloading and building the STM32MPU distribution for Android™, make sure your system meets the following requirements:

- A 64-bit Linux® environment.
- At least 150 Gbytes of free disk space. If you conduct multiple builds, even more space is required.
- At least 8 Gbytes of RAM/swap. If you are running Linux on a virtual machine, at least 16 Gbytes of RAM/swap are required.

For more details, refer to the [requirements page](#) of the AOSP website.

Use the following commands to install the packages required to build an environment for Android (Distribution Package), after having installed the required packages [listed on Android website](#):



```
sudo apt-get update
sudo apt-get install chrpath curl libxml2-utils gdisk pv python-pycryptopp python-crypto autotools-dev automake libusb-1.0-0-dev
```



To ensure USB communication (with ADB) between the host and the device, see [ADB § Device Connection](#).

To run Android-provided tests (CTS and VTS), see [Android Platform Testing](#).

At this stage: Your environment is ready for Android build, debug and test.

3.3 Additional configurations

- Allow up to 16 partitions per mmc

By default, on Linux system, a maximum of 8 partitions are allowed on mmc. All Packages (Starter Package, ...) need more than 10 partitions for the storage device. In order to extend the number of partitions per device to 16, the following options must be added to modprobe:

```
PC $> echo 'options mmc_block perdev_minors=16' > /tmp/mmc_block.conf
PC $> sudo mv /tmp/mmc_block.conf /etc/modprobe.d/mmc_block.conf
```

- Check for *locale* setup

Required for *Distribution Package*.

The *locale* setting is used by some applications/commands (including by *Distribution Package* applications/commands). Verify that the *locale* settings are as follows:

```
PC $> locale
LANG=en-US.UTF-8
```

In case the *locale* command returns a different configuration than the one shown above, it must be reconfigured as follows:

```
PC $> sudo update-locale LANG=en_US.UTF-8
```

- Add user in basics groups

The *user* login should belong to the basic Linux groups such as **disk**, **tty**, **dialout** or **plugdev**

Use the command *groups* to list groups for the current user:

```
PC $> groups
```

If needed add *user* to the missing *<groups>*:

```
PC $> sudo adduser $USER <group>
```

Then **reboot** the PC.



3.4 Setup *Git* user information

Required for *Developer Package* and *Distribution Package*.

The User Information is needed by git^[3] in case *commit* and/or *push* commands are being used :

```
PC $> git config --global user.name "Your Name"  
PC $> git config --global user.email "you@example.com"
```



4 Windows PC

Starter Package may run on Windows.

Developer Package and *Distribution Package* require a Linux environment.

Warning

ST solutions, while reportedly functional when running on a Linux Virtual machine, are only validated for Linux native setups ...

There are several ways to run Linux system on top of a Windows host PC, ST recommends to use a Virtual Machine System:

1. Install a virtual machine such as VMWare ^[4]
2. Setup a **64 bits** Ubuntu image compatible with your virtual machine

ST, in an experimental way, has also run *Developer Package* and *Distribution Package* on a WSL2 (Windows Subsystem for Linux 2); see [WSL2](#) chapter.

4.1 Virtual Machine System

4.1.1 Virtual Machine installation

ST has selected VMWare as Linux virtual machine solution.

VMWare is a commercial company specialized in virtualization solutions. The available solutions to support a virtual Linux machine on a Windows PC are:

- VMWare Workstation Player (paid solution) for commercial use (download here ^[5])
- VMWare Workstation Player (free solution) for home use (download here ^[6])

Please proceed with the installation of the virtual machine.

Before running the virtual machine, make sure the virtualization is activated in the BIOS (it should be activated by default for any retail PC).

4.1.2 Download the Ubuntu image for the virtual machine

The "osboxes.org" ^[7] website provides virtual machine images compatible with VMWare(*.vmdk).

ecosystem release v2.1.0  : Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 20.04 (64bits).

ecosystem release v2.0.0  : Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 16.04 (64bits).

Download the 64 bits Ubuntu image available at ^[8] and:

1. Unzip the downloaded file
2. In VMware create a virtual machine using the Ubuntu virtual disk downloaded from osboxes.org.

The recommended usage is to dedicate, at least, half of the host machine to the virtual machine:



- CPU: 2 cores at least,
- RAM: 6 Gbytes or more is a good choice (the more RAM allocated to Virtual Machine the better - the RAM allocated to Virtual Machine must be 4GB minimum),
- Network: NAT is good and an easy way to benefit form a network connection within the virtual machine.

Virutal size of virtual disk downloaded from osboxes.org is about 500GB. Even if the real size of the file of the virtual disk is less at beginning, the size could growth up to 500GB over compiling distribution package or development package.



Information

For VMware, you need first to create a default virtual machine then add the `.vmdk` file, previously downloaded.

Please refer to the [VMwarePlayer screenshot tutorial](#).

4.1.3 Launch of Ubuntu image



Warning

For "AZERTY" keyboard users:

The default keyboard configuration is "QWERTY".

In order to configure the keyboard for "AZERTY", start by opening a session (take care that the keyboard layout is QWERTY).

TIP: the password for the default user "*osboxes.org*" is "*osboxes.org*".

TIP: the '.' character is obtained by clicking '.' on an AZERTY keyboard configured in QWERTY.

Once the session is opened, click the 'En' icon on top/right of the screen, select the French ('Fr') keyboard layout and move it to the first position in the list.

Optionally the 'En' keyboard can be completely removed. If the 'Fr' option is not present, it can be added with the 'Text entry setting' menu.

Default **Credentials** of the Ubuntu are set to "**osboxes.org**" for both login and password.



Warning

Adjust screen resolution:

The (default) resolution used by the virtual machine is 800x600 (smallest available). It is not automatically adjusted to the display resolution. In order to adjust the resolution, click the "settings" icon ('toothed wheel' on top/right of the screen), then "system settings ..." > "display" and select the appropriate resolution for the display (do not to forget to click the "Apply" button on bottom/left of the "Screen Resolution Setting" window).

For a better experience with the VMware virtual machine, install "vmware-tools" in order to be able to use the clipboard to drag-and-drop and copy/paste files between VMware and Windows. A step-by-step installation procedure of **vmware-tools** is available in the document: [PreRequisite-Vmware-tools.pdf](#)

The virtual machine is up and running!

The Ubuntu setup must be finalized according recommendations provided in [Linux PC chapter](#)



Warning

USB connection's speed:



USB connection is requested for accessing STLink (debugger and serial port) and by STM32CubeProgrammer. The speed of the USB connection between Linux running in the virtual machine and the external USB devices can be severely impacted by:

- the virtual machine USB setup;
- the USB controller in the host PC;
- the USB device connected to host PC;
- any USB hub between the USB host and the USB device.

If the speed of your USB connection is too low, we suggest to:

- try different USB configurations of the virtual machine;
- connect the USB device directly on the host USB port (without any USB hub);
- try connecting the USB device to another USB port of the host (some PC have different USB controller on different USB port).

4.2 WSL2 (experimental)

Even if STMicroelectronics strongly recommends to use a Linux® environment, the *Developer Package* and *Distribution Package* works in WSL2 (Windows Sub-system Linux 2) environment. WSL is a feature provided by **Windows 10®**. ST has run unsuccessfully *Developer Package* and *Distribution Package* on WSL but successfully on WSL2. WSL2 is available on Windows 10® since build 18917.

WSL 2 is a new version of the architecture that powers the Windows Subsystem for Linux to run ELF64 Linux binaries on Windows (more details on aka.ms/wsl2).

- WSL2 - Installation :
 - To install WSL2 please read this webpage: <https://docs.microsoft.com/fr-fr/windows/wsl/wsl2-install>
 - Once WSL2 installed, jump to chapter #Linux_PC to make your WSL2 ready to run *Developer Package* and/or *Distribution Package*.
- WSL2 - Limitations :
 - WSL2 up to now (09/2019) does not support hardware such as USB devices, serial, ... (more details).
This means, STM32CubeProgrammer should be used through native Windows
 - WSL2 files are not browsable from Windows native file explorer.
To share files between WSL2 and Windows, the preferred way is to use the mount point `/mnt/c` from WSL2 and do copies.
- WSL2 - Tips :
 - Launch graphical application : On wiki.ubuntu.com the page on WSL contains a chapter Running Graphical Applications.

4.3 References

- Supported Linux Distributionsl
- [https://en.wikipedia.org/wiki/Corkscrew_\(program\)](https://en.wikipedia.org/wiki/Corkscrew_(program))
- Git
- <http://vmware.com>
- https://my.vmware.com/en/web/vmware/free#desktop_end_user_computing/vmware_workstation_player/15_0
- <https://www.vmware.com/products/workstation-player/workstation-player-evaluation.html>
- <http://osboxes.org>
- <https://www.osboxes.org/ubuntu/#ubuntu-1804-vmware>



Linux® is a registered trademark of Linus Torvalds.

Microprocessor Unit

Central processing unit

Random Access Memory (Early computer memories generally had serial access. Memories where any given address can be accessed when desired were then called "random access" to distinguish them from the memories where contents can only be accessed in a fixed order. The term is used today for volatile random-access semiconductor memories.)

Android Open Source Project

Android debug bridge (Android specific)

Compatibility Test Suite (Android specific) or Clear to send (in UART context)

Vendor Test Suite (Android specific)

ST in-circuit debugger and programmer for the STM8 and STM32 microcontroller families (See ST-LINK for more details)

Stable: 26.09.2019 - 14:30 / Revision: 26.09.2019 - 12:48

Information

Recommended setup: Native Linux PC

Contents

1 Purpose	26
2 Recommended PC configurations	27
3 Linux PC	28
3.1 Check Internet access	28
3.2 Install extra packages	29
3.2.1 Install extra packages for Android	30
3.3 Additional configurations	31
3.4 Setup <i>Git</i> user information	32
4 Windows PC	33
4.1 Virtual Machine System	33
4.1.1 Virtual Machine installation	33
4.1.2 Download the Ubuntu image for the virtual machine	33
4.1.3 Launch of Ubuntu image	34
4.2 WSL2 (experimental)	35
4.3 References	35



1 Purpose

This article explains and describes the hardware configuration required to be able to activate and run the STM32 MPU platforms.



2 Recommended PC configurations

The PC requirements depend on the [Package](#) you want to use.

The table below guides through the selection and configuration of the host PC environment according the targeted [Package](#):

Host Environment	Starter Package	Developer Package	Distribution Package
Windows (64 bits) Tested with Windows7 and Windows10 Preferred version Windows 10	native	Virtual Machine	Virtual Machine
Linux (64 bits) Tested with Ubuntu 18.04 and 20.04	native	native + additional packages (see Linux PC chapter)	native + additional packages (see Linux PC chapter)

There are no absolute minimal requirements regarding the PC hardware configuration, however ST recommends to meet or exceed the following hardware configurations when using *Developer Package* or *Distribution Package*.

The table below correspond to the minimal validated configuration:

Hardware item	Minimal validated configuration	Comments / Recommendations
CPU	core i5-2540M @ 2.6GHz 2 cores (4 threads) 3MB cache	64 bits instruction set is mandatory 8 cores/threads or more is a good config moreover for <i>Developer Package</i> and <i>Distribution Package</i> .
RAM	8GB	16GB or more is recommended especially for <i>Virtual Machine</i> setup , <i>Developer Package</i> and <i>Distribution Package</i> .
Hard Drive	320GB	1TB is probably a better config when using <i>Distribution Package</i>



3 Linux PC

A Linux PC with **Ubuntu 18.04** is the recommended setup. Other Ubuntu revisions should also be supported, please refer to Yocto Manual^[1].

i Information

ecosystem release v2.1.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 20.04 LTS).

i Information

ecosystem release v2.0.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 16.04 LTS).

3.1 Check Internet access

- An Internet access through http and https protocols must be provided.

Required for *Developer Package* and *Distribution Package* at least.

The command below allows to check for Internet access through http/https protocols:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```

If a 'OK' message is returned, the network is well configured. In such case, skip the rest of this section and jump to next one (Install extra packages).

Any other situation likely indicates the need for a proxy for http/https protocols.

The best solution to set a proxy for http/https protocols is via the shell variables `http_proxy` and `https_proxy`:

```
PC $> export http_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
PC $> export https_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
```

Because your password may contains "special characters" you need to translate your password into ASCII hexacode. By this way you can translate `<MyProxyPassword>` into hexacode by using this command :

```
PC $> echo -n "<MyProxyPassword>" | od -A n -t x1 -w128 | head -1 | tr " " "%"
```

Check again the Internet access with command:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```



- Internet access for *sudo* commands

Required for *Distribution Package*.

sudo commands are executed in the *root* user environment; by default, no Internet proxy settings are applied for *root* user. *Root* user should be able to browse Internet, after creation of an alias passing the proxy settings on *sudo* command:

```
PC $> alias sudo='sudo http_proxy=$http_proxy'
```

Check that the *sudo* commands is successful (requires Internet access):

```
PC $> sudo apt-get update
```

- Internet over *git://*, *ssh://* and others specifics protocols

Required for *Distribution Package*.

In addition to http/https protocols (used in 90% of the Internet traffic), some other protocols like *git://* or *ssh://* may be required.

For example in the context of the *Distribution Package*, some "git fetch" commands could require "git://" protocols".

In order to support these protocols through a proxy, the best way is to directly setup the proxy in the `$HOME/.gitconfig` file (core.gitproxy) and use a tool like *cockscrew*^[2] in order to tunnel the *git://* flow into the http flow:

```
PC $> sudo apt-get update
PC $> sudo apt-get install cockscrew

PC $> git config --replace-all --global core.gitproxy "$HOME/bin/git-proxy.sh"
PC $> git config --add --global core.gitproxy "none for <MyPrivateNetworkDomain>"
(optionnal and for example .st.com, localhost, ...)
PC $> echo 'exec cockscrew <MyProxyServerUrl> <MyProxyPort> $* $HOME/.git-proxy.auth' >
$HOME/bin/git-proxy.sh
PC $> chmod 700 $HOME/bin/git-proxy.sh
PC $> echo '<MyProxyLogin>:<MyProxyPassword>' > $HOME/.git-proxy.auth
PC $> chmod 600 $HOME/.git-proxy.auth
```

Here is a command to test this proxy settings:

```
PC $> git ls-remote git://git.openembedded.org/openembedded-core > /dev/null && echo OK
|| echo KO
```

The command should return 'OK', else proxy settings are wrong.

3.2 Install extra packages

Required for *Developer Package* and *Distribution Package*.

In order to do basic development tasks, basic cross-compilation (via *Developer Package*) or more complex cross-compilation as OpenEmbedded does (via *Distribution Package*), some extra Ubuntu packages should be installed:

- Packages required by OpenEmbedded/Yocto (details here):



```
PC $> sudo apt-get update
PC $> sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib build-essential chrpath socat cpio python3 python3-pip python3-pexpect xz-utils debianutils iputils-ping python3-git python3-jinja2 libegl1-mesa libsdl1.2-dev pylint3 pylint xterm
PC $> sudo apt-get install make xsltproc docbook-utils fop dblatex xmlto
```

- Packages needed for some "Developer Package" use cases:

```
PC $> sudo apt-get install libncurses5-dev libncursesw5-dev libssl-dev linux-headers-generic u-boot-tools device-tree-compiler bison flex g++ libyaml-dev
```

- Package for repo (used to download the "Distribution Package" source code):

Please follow official instructions to install [repo](#)
For Ubuntu 16.04 you should use the legacy repo [old-repo-python2](#) chapter

- Some useful tools:

```
PC $> sudo apt-get install coreutils bsdmainutils sed curl bc lrzsz corkscrew cvs subversion mercurial nfs-common nfs-kernel-server libarchive-zip-perl dos2unix texi2html diffstat libxml2-utils
```

You can also install a Java Runtime Engine, this is required for [STM32CubeMX](#) and [STM32CubeProgrammer](#)

```
PC $> sudo apt-get install default-jre
```

3.2.1 Install extra packages for Android

Below information is related to the Android™ distribution

Before downloading and building the STM32MPU distribution for Android™, make sure your system meets the following requirements:

- A 64-bit Linux® environment.
- At least 150 Gbytes of free disk space. If you conduct multiple builds, even more space is required.
- At least 8 Gbytes of RAM/swap. If you are running Linux on a virtual machine, at least 16 Gbytes of RAM/swap are required.

For more details, refer to the [requirements page](#) of the AOSP website.

Use the following commands to install the packages required to build an environment for Android (Distribution Package), after having installed the required packages [listed on Android website](#):



```
sudo apt-get update
sudo apt-get install chrpath curl libxml2-utils gdisk pv python-pycryptopp python-crypto autotools-dev automake libusb-1.0-0-dev
```



To ensure USB communication (with ADB) between the host and the device, see [ADB § Device Connection](#).

To run Android-provided tests (CTS and VTS), see [Android Platform Testing](#).

At this stage: Your environment is ready for Android build, debug and test.

3.3 Additional configurations

- Allow up to 16 partitions per mmc

By default, on Linux system, a maximum of 8 partitions are allowed on mmc. All Packages (Starter Package, ...) need more than 10 partitions for the storage device. In order to extend the number of partitions per device to 16, the following options must be added to modprobe:

```
PC $> echo 'options mmc_block perdev_minors=16' > /tmp/mmc_block.conf
PC $> sudo mv /tmp/mmc_block.conf /etc/modprobe.d/mmc_block.conf
```

- Check for *locale* setup

Required for *Distribution Package*.

The *locale* setting is used by some applications/commands (including by *Distribution Package* applications/commands). Verify that the *locale* settings are as follows:

```
PC $> locale
LANG=en-US.UTF-8
```

In case the *locale* command returns a different configuration than the one shown above, it must be reconfigured as follows:

```
PC $> sudo update-locale LANG=en_US.UTF-8
```

- Add user in basics groups

The *user* login should belong to the basic Linux groups such as **disk**, **tty**, **dialout** or **plugdev**

Use the command *groups* to list groups for the current user:

```
PC $> groups
```

If needed add *user* to the missing *<groups>*:

```
PC $> sudo adduser $USER <group>
```

Then **reboot** the PC.



3.4 Setup *Git* user information

Required for *Developer Package* and *Distribution Package*.

The User Information is needed by git^[3] in case *commit* and/or *push* commands are being used :

```
PC $> git config --global user.name "Your Name"  
PC $> git config --global user.email "you@example.com"
```




4 Windows PC

Starter Package may run on Windows.

Developer Package and *Distribution Package* require a Linux environment.

Warning

ST solutions, while reportedly functional when running on a Linux Virtual machine, are only validated for Linux native setups ...

There are several ways to run Linux system on top of a Windows host PC, ST recommends to use a Virtual Machine System:

1. Install a virtual machine such as VMWare ^[4]
2. Setup a **64 bits** Ubuntu image compatible with your virtual machine

ST, in an experimental way, has also run *Developer Package* and *Distribution Package* on a WSL2 (Windows Subsystem for Linux 2); see [WSL2](#) chapter.

4.1 Virtual Machine System

4.1.1 Virtual Machine installation

ST has selected VMWare as Linux virtual machine solution.

VMWare is a commercial company specialized in virtualization solutions. The available solutions to support a virtual Linux machine on a Windows PC are:

- VMWare Workstation Player (paid solution) for commercial use (download here ^[5])
- VMWare Workstation Player (free solution) for home use (download here ^[6])

Please proceed with the installation of the virtual machine.

Before running the virtual machine, make sure the virtualization is activated in the BIOS (it should be activated by default for any retail PC).

4.1.2 Download the Ubuntu image for the virtual machine

The "osboxes.org" ^[7] website provides virtual machine images compatible with VMWare (*.vmdk).

ecosystem release v2.1.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 20.04 (64bits).**

ecosystem release v2.0.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 16.04 (64bits).**

Download the 64 bits Ubuntu image available at ^[8] and:

1. Unzip the downloaded file
2. In VMware create a virtual machine using the Ubuntu virtual disk downloaded from osboxes.org.

The recommended usage is to dedicate, at least, half of the host machine to the virtual machine:



- CPU: 2 cores at least,
- RAM: 6 Gbytes or more is a good choice (the more RAM allocated to Virtual Machine the better - the RAM allocated to Virtual Machine must be 4GB minimum),
- Network: NAT is good and an easy way to benefit form a network connection within the virtual machine.

Virutal size of virtual disk downloaded from osboxes.org is about 500GB. Even if the real size of the file of the virtual disk is less at beginning, the size could growth up to 500GB over compiling distribution package or development package.



Information

For VMware, you need first to create a default virtual machine then add the `.vmdk` file, previously downloaded.

Please refer to the [VMwarePlayer screenshot tutorial](#).

4.1.3 Launch of Ubuntu image



Warning

For "AZERTY" keyboard users:

The default keyboard configuration is "QWERTY".

In order to configure the keyboard for "AZERTY", start by opening a session (take care that the keyboard layout is QWERTY).

TIP: the password for the default user "*osboxes.org*" is "*osboxes.org*".

TIP: the '.' character is obtained by clicking '.' on an AZERTY keyboard configured in QWERTY.

Once the session is opened, click the 'En' icon on top/right of the screen, select the French ('Fr') keyboard layout and move it to the first position in the list.

Optionally the 'En' keyboard can be completely removed. If the 'Fr' option is not present, it can be added with the 'Text entry setting' menu.

Default **Credentials** of the Ubuntu are set to "**osboxes.org**" for both login and password.



Warning

Adjust screen resolution:

The (default) resolution used by the virtual machine is 800x600 (smallest available). It is not automatically adjusted to the display resolution. In order to adjust the resolution, click the "settings" icon ('toothed wheel' on top/right of the screen), then "system settings ..." > "display" and select the appropriate resolution for the display (do not to forget to click the "Apply" button on bottom/left of the "Screen Resolution Setting" window).

For a better experience with the VMware virtual machine, install "vmware-tools" in order to be able to use the clipboard to drag-and-drop and copy/paste files between VMware and Windows. A step-by-step installation procedure of **vmware-tools** is available in the document: [PreRequisite-Vmware-tools.pdf](#)

The virtual machine is up and running!

The Ubuntu setup must be finalized according recommendations provided in [Linux PC chapter](#)



Warning

USB connection's speed:



USB connection is requested for accessing STLink (debugger and serial port) and by STM32CubeProgrammer. The speed of the USB connection between Linux running in the virtual machine and the external USB devices can be severely impacted by:

- the virtual machine USB setup;
- the USB controller in the host PC;
- the USB device connected to host PC;
- any USB hub between the USB host and the USB device.

If the speed of your USB connection is too low, we suggest to:

- try different USB configurations of the virtual machine;
- connect the USB device directly on the host USB port (without any USB hub);
- try connecting the USB device to another USB port of the host (some PC have different USB controller on different USB port).

4.2 WSL2 (experimental)

Even if STMicroelectronics strongly recommends to use a Linux® environment, the *Developer Package* and *Distribution Package* works in WSL2 (Windows Sub-system Linux 2) environment. WSL is a feature provided by **Windows 10®**. ST has run unsuccessfully *Developer Package* and *Distribution Package* on WSL but successfully on WSL2. WSL2 is available on Windows 10® since build 18917.

WSL 2 is a new version of the architecture that powers the Windows Subsystem for Linux to run ELF64 Linux binaries on Windows (more details on aka.ms/wsl2).

- WSL2 - Installation :
 - To install WSL2 please read this webpage: <https://docs.microsoft.com/fr-fr/windows/wsl/wsl2-install>
 - Once WSL2 installed, jump to chapter #Linux_PC to make your WSL2 ready to run *Developer Package* and/or *Distribution Package*.
- WSL2 - Limitations :
 - WSL2 up to now (09/2019) does not support hardware such as USB devices, serial, ... (more details).
This means, STM32CubeProgrammer should be used through native Windows
 - WSL2 files are not browsable from Windows native file explorer.
To share files between WSL2 and Windows, the preferred way is to use the mount point `/mnt/c` from WSL2 and do copies.
- WSL2 - Tips :
 - Launch graphical application : On wiki.ubuntu.com the page on WSL contains a chapter Running Graphical Applications.

4.3 References

- Supported Linux Distributionsl
- [https://en.wikipedia.org/wiki/Corkscrew_\(program\)](https://en.wikipedia.org/wiki/Corkscrew_(program))
- Git
- <http://vmware.com>
- https://my.vmware.com/en/web/vmware/free#desktop_end_user_computing/vmware_workstation_player/15_0
- <https://www.vmware.com/products/workstation-player/workstation-player-evaluation.html>
- <http://osboxes.org>
- <https://www.osboxes.org/ubuntu/#ubuntu-1804-vmware>



Linux® is a registered trademark of Linus Torvalds.

Microprocessor Unit

Central processing unit

Random Access Memory (Early computer memories generally had serial access. Memories where any given address can be accessed when desired were then called "random access" to distinguish them from the memories where contents can only be accessed in a fixed order. The term is used today for volatile random-access semiconductor memories.)

Android Open Source Project

Android debug bridge (Android specific)

Compatibility Test Suite (Android specific) or Clear to send (in UART context)

Vendor Test Suite (Android specific)

ST in-circuit debugger and programmer for the STM8 and STM32 microcontroller families (See ST-LINK for more details)

Stable: 25.03.2021 - 16:36 / Revision: 25.03.2021 - 16:36

A quality version of this page, approved on 17 November 2020, was based off this revision.

Information

Recommended setup: Native Linux PC

Contents

1 Purpose	37
2 Recommended PC configurations	38
3 Linux PC	39
3.1 Check Internet access	39
3.2 Install extra packages	40
3.2.1 Install extra packages for Android	41
3.3 Additional configurations	42
3.4 Setup <i>Git</i> user information	43
4 Windows PC	44
4.1 Virtual Machine System	44
4.1.1 Virtual Machine installation	44
4.1.2 Download the Ubuntu image for the virtual machine	44
4.1.3 Launch of Ubuntu image	45
4.2 WSL2 (experimental)	46
4.3 References	46



1 Purpose

This article explains and describes the hardware configuration required to be able to activate and run the STM32 MPU platforms.



2 Recommended PC configurations

The PC requirements depend on the [Package](#) you want to use.

The table below guides through the selection and configuration of the host PC environment according the targeted [Package](#):

Host Environment	Starter Package	Developer Package	Distribution Package
Windows (64 bits) Tested with Windows7 and Windows10 Preferred version Windows 10	native	Virtual Machine	Virtual Machine
Linux (64 bits) Tested with Ubuntu 18.04 and 20.04	native	native + additional packages (see Linux PC chapter)	native + additional packages (see Linux PC chapter)

There are no absolute minimal requirements regarding the PC hardware configuration, however ST recommends to meet or exceed the following hardware configurations when using *Developer Package* or *Distribution Package*.

The table below correspond to the minimal validated configuration:

Hardware item	Minimal validated configuration	Comments / Recommendations
CPU	core i5-2540M @ 2.6GHz 2 cores (4 threads) 3MB cache	64 bits instruction set is mandatory 8 cores/threads or more is a good config moreover for <i>Developer Package</i> and <i>Distribution Package</i> .
RAM	8GB	16GB or more is recommended especially for <i>Virtual Machine</i> setup , <i>Developer Package</i> and <i>Distribution Package</i> .
Hard Drive	320GB	1TB is probably a better config when using <i>Distribution Package</i>



3 Linux PC

A Linux PC with **Ubuntu 18.04** is the recommended setup. Other Ubuntu revisions should also be supported, please refer to Yocto Manual^[1].

Information

ecosystem release v2.1.0

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 20.04 LTS).

Information

ecosystem release v2.0.0

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 16.04 LTS).

3.1 Check Internet access

- An Internet access through http and https protocols must be provided.

Required for *Developer Package* and *Distribution Package* at least.

The command below allows to check for Internet access through http/https protocols:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo "No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```

If a 'OK' message is returned, the network is well configured. In such case, skip the rest of this section and jump to next one (Install extra packages).

Any other situation likely indicates the need for a proxy for http/https protocols.

The best solution to set a proxy for http/https protocols is via the shell variables `http_proxy` and `https_proxy`:

```
PC $> export http_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
PC $> export https_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
```

Because your password may contains "special characters" you need to translate your password into ASCII hexacode. By this way you can translate `<MyProxyPassword>` into hexacode by using this command :

```
PC $> echo -n "<MyProxyPassword>" | od -A n -t x1 -w128 | head -1 | tr " " "%"
```

Check again the Internet access with command:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo "No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```



- Internet access for *sudo* commands

Required for *Distribution Package*.

sudo commands are executed in the *root* user environment; by default, no Internet proxy settings are applied for *root* user. *Root* user should be able to browse Internet, after creation of an alias passing the proxy settings on *sudo* command:

```
PC $> alias sudo='sudo http_proxy=$http_proxy'
```

Check that the *sudo* commands is successful (requires Internet access):

```
PC $> sudo apt-get update
```

- Internet over *git://*, *ssh://* and others specifics protocols

Required for *Distribution Package*.

In addition to http/https protocols (used in 90% of the Internet traffic), some other protocols like *git://* or *ssh://* may be required.

For example in the context of the *Distribution Package*, some "git fetch" commands could require "git://" protocols".

In order to support these protocols through a proxy, the best way is to directly setup the proxy in the `$HOME/.gitconfig` file (core.gitproxy) and use a tool like *cockscrew*^[2] in order to tunnel the *git://* flow into the http flow:

```
PC $> sudo apt-get update
PC $> sudo apt-get install cockscrew

PC $> git config --replace-all --global core.gitproxy "$HOME/bin/git-proxy.sh"
PC $> git config --add --global core.gitproxy "none for <MyPrivateNetworkDomain>"
(optionnal and for example .st.com, localhost, ...)
PC $> echo 'exec cockscrew <MyProxyServerUrl> <MyProxyPort> $* $HOME/.git-proxy.auth' >
$HOME/bin/git-proxy.sh
PC $> chmod 700 $HOME/bin/git-proxy.sh
PC $> echo '<MyProxyLogin>:<MyProxyPassword>' > $HOME/.git-proxy.auth
PC $> chmod 600 $HOME/.git-proxy.auth
```

Here is a command to test this proxy settings:

```
PC $> git ls-remote git://git.openembedded.org/openembedded-core > /dev/null && echo OK
|| echo KO
```

The command should return 'OK', else proxy settings are wrong.

3.2 Install extra packages

Required for *Developer Package* and *Distribution Package*.

In order to do basic development tasks, basic cross-compilation (via *Developer Package*) or more complex cross-compilation as OpenEmbedded does (via *Distribution Package*), some extra Ubuntu packages should be installed:

- Packages required by OpenEmbedded/Yocto (details here):



```
PC $> sudo apt-get update
PC $> sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib build-essential chrpath socat cpio python3 python3-pip python3-pexpect xz-utils debianutils iputils-ping python3-git python3-jinja2 libegl1-mesa libsdl1.2-dev pylint3 pylint xterm
PC $> sudo apt-get install make xsltproc docbook-utils fop dblatex xmlto
```

- Packages needed for some "Developer Package" use cases:

```
PC $> sudo apt-get install libncurses5-dev libncursesw5-dev libssl-dev linux-headers-generic u-boot-tools device-tree-compiler bison flex g++ libyaml-dev
```

- Package for repo (used to download the "Distribution Package" source code):

Please follow official instructions to install [repo](#)
For Ubuntu 16.04 you should use the legacy repo [old-repo-python2](#) chapter

- Some useful tools:

```
PC $> sudo apt-get install coreutils bsdmainutils sed curl bc lrzsz corkscrew cvs subversion mercurial nfs-common nfs-kernel-server libarchive-zip-perl dos2unix texi2html diffstat libxml2-utils
```

You can also install a Java Runtime Engine, this is required for [STM32CubeMX](#) and [STM32CubeProgrammer](#)

```
PC $> sudo apt-get install default-jre
```

3.2.1 Install extra packages for Android

Below information is related to the Android™ distribution

Before downloading and building the STM32MPU distribution for Android™, make sure your system meets the following requirements:

- A 64-bit Linux® environment.
- At least 150 Gbytes of free disk space. If you conduct multiple builds, even more space is required.
- At least 8 Gbytes of RAM/swap. If you are running Linux on a virtual machine, at least 16 Gbytes of RAM/swap are required.

For more details, refer to the [requirements page](#) of the AOSP website.

Use the following commands to install the packages required to build an environment for Android (Distribution Package), after having installed the required packages [listed on Android website](#):



```
sudo apt-get update
sudo apt-get install chrpath curl libxml2-utils gdisk pv python-pycryptopp python-crypto autotools-dev automake libusb-1.0-0-dev
```



To ensure USB communication (with ADB) between the host and the device, see [ADB § Device Connection](#).

To run Android-provided tests (CTS and VTS), see [Android Platform Testing](#).

At this stage: Your environment is ready for Android build, debug and test.

3.3 Additional configurations

- Allow up to 16 partitions per mmc

By default, on Linux system, a maximum of 8 partitions are allowed on mmc. All Packages (Starter Package, ...) need more than 10 partitions for the storage device. In order to extend the number of partitions per device to 16, the following options must be added to modprobe:

```
PC $> echo 'options mmc_block perdev_minors=16' > /tmp/mmc_block.conf
PC $> sudo mv /tmp/mmc_block.conf /etc/modprobe.d/mmc_block.conf
```

- Check for *locale* setup

Required for *Distribution Package*.

The *locale* setting is used by some applications/commands (including by *Distribution Package* applications/commands). Verify that the *locale* settings are as follows:

```
PC $> locale
LANG=en-US.UTF-8
```

In case the *locale* command returns a different configuration than the one shown above, it must be reconfigured as follows:

```
PC $> sudo update-locale LANG=en_US.UTF-8
```

- Add user in basics groups

The *user* login should belong to the basic Linux groups such as **disk**, **tty**, **dialout** or **plugdev**

Use the command *groups* to list groups for the current user:

```
PC $> groups
```

If needed add *user* to the missing *<groups>*:

```
PC $> sudo adduser $USER <group>
```

Then **reboot** the PC.



3.4 Setup *Git* user information

Required for *Developer Package* and *Distribution Package*.

The User Information is needed by git^[3] in case *commit* and/or *push* commands are being used :

```
PC $> git config --global user.name "Your Name"  
PC $> git config --global user.email "you@example.com"
```



4 Windows PC

Starter Package may run on Windows.

Developer Package and *Distribution Package* require a Linux environment.

Warning

ST solutions, while reportedly functional when running on a Linux Virtual machine, are only validated for Linux native setups ...

There are several ways to run Linux system on top of a Windows host PC, ST recommends to use a Virtual Machine System:

1. Install a virtual machine such as VMWare ^[4]
2. Setup a **64 bits** Ubuntu image compatible with your virtual machine

ST, in an experimental way, has also run *Developer Package* and *Distribution Package* on a WSL2 (Windows Subsystem for Linux 2); see [WSL2](#) chapter.

4.1 Virtual Machine System

4.1.1 Virtual Machine installation

ST has selected VMWare as Linux virtual machine solution.

VMWare is a commercial company specialized in virtualization solutions. The available solutions to support a virtual Linux machine on a Windows PC are:

- VMWare Workstation Player (paid solution) for commercial use (download here ^[5])
- VMWare Workstation Player (free solution) for home use (download here ^[6])

Please proceed with the installation of the virtual machine.

Before running the virtual machine, make sure the virtualization is activated in the BIOS (it should be activated by default for any retail PC).

4.1.2 Download the Ubuntu image for the virtual machine

The "osboxes.org" ^[7] website provides virtual machine images compatible with VMWare (*.vmdk).

ecosystem release v2.1.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 20.04 (64bits).**

ecosystem release v2.0.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 16.04 (64bits).**

Download the 64 bits Ubuntu image available at ^[8] and:

1. Unzip the downloaded file
2. In VMware create a virtual machine using the Ubuntu virtual disk downloaded from osboxes.org.

The recommended usage is to dedicate, at least, half of the host machine to the virtual machine:



- CPU: 2 cores at least,
- RAM: 6 Gbytes or more is a good choice (the more RAM allocated to Virtual Machine the better - the RAM allocated to Virtual Machine must be 4GB minimum),
- Network: NAT is good and an easy way to benefit form a network connection within the virtual machine.

Virutal size of virtual disk downloaded from osboxes.org is about 500GB. Even if the real size of the file of the virtual disk is less at beginning, the size could growth up to 500GB over compiling distribution package or development package.

Information

For VMware, you need first to create a default virtual machine then add the `.vmdk` file, previously downloaded.

Please refer to the [VMwarePlayer screenshot tutorial](#).

4.1.3 Launch of Ubuntu image

Warning

For "AZERTY" keyboard users:

The default keyboard configuration is "QWERTY".

In order to configure the keyboard for "AZERTY", start by opening a session (take care that the keyboard layout is QWERTY).

TIP: the password for the default user "*osboxes.org*" is "*osboxes.org*".

TIP: the '.' character is obtained by clicking '.' on an AZERTY keyboard configured in QWERTY.

Once the session is opened, click the 'En' icon on top/right of the screen, select the French ('Fr') keyboard layout and move it to the first position in the list.

Optionally the 'En' keyboard can be completely removed. If the 'Fr' option is not present, it can be added with the 'Text entry setting' menu.

Default **Credentials** of the Ubuntu are set to "**osboxes.org**" for both login and password.

Warning

Adjust screen resolution:

The (default) resolution used by the virtual machine is 800x600 (smallest available). It is not automatically adjusted to the display resolution. In order to adjust the resolution, click the "settings" icon ('toothed wheel' on top/right of the screen), then "system settings ..." > "display" and select the appropriate resolution for the display (do not to forget to click the "Apply" button on bottom/left of the "Screen Resolution Setting" window).

For a better experience with the VMware virtual machine, install "vmware-tools" in order to be able to use the clipboard to drag-and-drop and copy/paste files between VMware and Windows. A step-by-step installation procedure of **vmware-tools** is available in the document: [PreRequisite-Vmware-tools.pdf](#)

The virtual machine is up and running!

The Ubuntu setup must be finalized according recommendations provided in [Linux PC chapter](#)

Warning

USB connection's speed:



USB connection is requested for accessing STLink (debugger and serial port) and by STM32CubeProgrammer. The speed of the USB connection between Linux running in the virtual machine and the external USB devices can be severely impacted by:

- the virtual machine USB setup;
- the USB controller in the host PC;
- the USB device connected to host PC;
- any USB hub between the USB host and the USB device.

If the speed of your USB connection is too low, we suggest to:

- try different USB configurations of the virtual machine;
- connect the USB device directly on the host USB port (without any USB hub);
- try connecting the USB device to another USB port of the host (some PC have different USB controller on different USB port).

4.2 WSL2 (experimental)

Even if STMicroelectronics strongly recommends to use a Linux® environment, the *Developer Package* and *Distribution Package* works in WSL2 (Windows Sub-system Linux 2) environment. WSL is a feature provided by **Windows 10®**. ST has run unsuccessfully *Developer Package* and *Distribution Package* on WSL but successfully on WSL2. WSL2 is available on Windows 10® since build 18917.

WSL 2 is a new version of the architecture that powers the Windows Subsystem for Linux to run ELF64 Linux binaries on Windows (more details on aka.ms/wsl2).

- WSL2 - Installation :
 - To install WSL2 please read this webpage: <https://docs.microsoft.com/fr-fr/windows/wsl/wsl2-install>
 - Once WSL2 installed, jump to chapter #Linux_PC to make your WSL2 ready to run *Developer Package* and/or *Distribution Package*.
- WSL2 - Limitations :
 - WSL2 up to now (09/2019) does not support hardware such as USB devices, serial, ... (more details).
This means, STM32CubeProgrammer should be used through native Windows
 - WSL2 files are not browsable from Windows native file explorer.
To share files between WSL2 and Windows, the preferred way is to use the mount point `/mnt/c` from WSL2 and do copies.
- WSL2 - Tips :
 - Launch graphical application : On wiki.ubuntu.com the page on WSL contains a chapter Running Graphical Applications.

4.3 References

- Supported Linux Distributionsl
- [https://en.wikipedia.org/wiki/Corkscrew_\(program\)](https://en.wikipedia.org/wiki/Corkscrew_(program))
- Git
- <http://vmware.com>
- https://my.vmware.com/en/web/vmware/free#desktop_end_user_computing/vmware_workstation_player/15_0
- <https://www.vmware.com/products/workstation-player/workstation-player-evaluation.html>
- <http://osboxes.org>
- <https://www.osboxes.org/ubuntu/#ubuntu-1804-vmware>



Linux® is a registered trademark of Linus Torvalds.

Microprocessor Unit

Central processing unit

Random Access Memory (Early computer memories generally had serial access. Memories where any given address can be accessed when desired were then called "random access" to distinguish them from the memories where contents can only be accessed in a fixed order. The term is used today for volatile random-access semiconductor memories.)

Android Open Source Project

Android debug bridge (Android specific)

Compatibility Test Suite (Android specific) or Clear to send (in UART context)

Vendor Test Suite (Android specific)

ST in-circuit debugger and programmer for the STM8 and STM32 microcontroller families (See ST-LINK for more details)

Stable: 20.12.2019 - 13:12 / Revision: 42.12.2019 - 12:53

Information

Recommended setup: Native Linux PC

Contents

1 Purpose	48
2 Recommended PC configurations	49
3 Linux PC	50
3.1 Check Internet access	50
3.2 Install extra packages	51
3.2.1 Install extra packages for Android	52
3.3 Additional configurations	53
3.4 Setup <i>Git</i> user information	54
4 Windows PC	55
4.1 Virtual Machine System	55
4.1.1 Virtual Machine installation	55
4.1.2 Download the Ubuntu image for the virtual machine	55
4.1.3 Launch of Ubuntu image	56
4.2 WSL2 (experimental)	57
4.3 References	57



1 Purpose

This article explains and describes the hardware configuration required to be able to activate and run the STM32 MPU platforms.



2 Recommended PC configurations

The PC requirements depend on the [Package](#) you want to use.

The table below guides through the selection and configuration of the host PC environment according the targeted [Package](#):

Host Environment	Starter Package	Developer Package	Distribution Package
Windows (64 bits) Tested with Windows7 and Windows10 Preferred version Windows 10	native	Virtual Machine	Virtual Machine
Linux (64 bits) Tested with Ubuntu 18.04 and 20.04	native	native + additional packages (see Linux PC chapter)	native + additional packages (see Linux PC chapter)

There are no absolute minimal requirements regarding the PC hardware configuration, however ST recommends to meet or exceed the following hardware configurations when using *Developer Package* or *Distribution Package*.

The table below correspond to the minimal validated configuration:

Hardware item	Minimal validated configuration	Comments / Recommendations
CPU	core i5-2540M @ 2.6GHz 2 cores (4 threads) 3MB cache	64 bits instruction set is mandatory 8 cores/threads or more is a good config moreover for <i>Developer Package</i> and <i>Distribution Package</i> .
RAM	8GB	16GB or more is recommended especially for <i>Virtual Machine</i> setup , <i>Developer Package</i> and <i>Distribution Package</i> .
Hard Drive	320GB	1TB is probably a better config when using <i>Distribution Package</i>



3 Linux PC

A Linux PC with **Ubuntu 18.04** is the recommended setup. Other Ubuntu revisions should also be supported, please refer to Yocto Manual^[1].

i Information

ecosystem release v2.1.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 20.04 LTS).

i Information

ecosystem release v2.0.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 16.04 LTS).

3.1 Check Internet access

- **An Internet access through http and https protocols must be provided.**

Required for *Developer Package* and *Distribution Package* at least.

The command below allows to check for Internet access through http/https protocols:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```

If a 'OK' message is returned, the network is well configured. In such case, skip the rest of this section and jump to next one (Install extra packages).

Any other situation likely indicates the need for a proxy for http/https protocols.

The best solution to set a proxy for http/https protocols is via the shell variables `http_proxy` and `https_proxy`:

```
PC $> export http_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
PC $> export https_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
```

Because your password may contains "special characters" you need to translate your password into ASCII hexacode. By this way you can translate `<MyProxyPassword>` into hexacode by using this command :

```
PC $> echo -n "<MyProxyPassword>" | od -A n -t x1 -w128 | head -1 | tr " " "%"
```

Check again the Internet access with command:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```



- Internet access for *sudo* commands

Required for *Distribution Package*.

sudo commands are executed in the *root* user environment; by default, no Internet proxy settings are applied for *root* user. *Root* user should be able to browse Internet, after creation of an alias passing the proxy settings on *sudo* command:

```
PC $> alias sudo='sudo http_proxy=$http_proxy'
```

Check that the *sudo* commands is successful (requires Internet access):

```
PC $> sudo apt-get update
```

- Internet over *git://*, *ssh://* and others specifics protocols

Required for *Distribution Package*.

In addition to http/https protocols (used in 90% of the Internet traffic), some other protocols like *git://* or *ssh://* may be required.

For example in the context of the *Distribution Package*, some "git fetch" commands could require "git://" protocols".

In order to support these protocols through a proxy, the best way is to directly setup the proxy in the `$HOME/.gitconfig` file (core.gitproxy) and use a tool like *cockscrew*^[2] in order to tunnel the *git://* flow into the http flow:

```
PC $> sudo apt-get update
PC $> sudo apt-get install cockscrew

PC $> git config --replace-all --global core.gitproxy "$HOME/bin/git-proxy.sh"
PC $> git config --add --global core.gitproxy "none for <MyPrivateNetworkDomain>"
(optionnal and for example .st.com, localhost, ...)
PC $> echo 'exec cockscrew <MyProxyServerUrl> <MyProxyPort> $* $HOME/.git-proxy.auth' >
$HOME/bin/git-proxy.sh
PC $> chmod 700 $HOME/bin/git-proxy.sh
PC $> echo '<MyProxyLogin>:<MyProxyPassword>' > $HOME/.git-proxy.auth
PC $> chmod 600 $HOME/.git-proxy.auth
```

Here is a command to test this proxy settings:

```
PC $> git ls-remote git://git.openembedded.org/openembedded-core > /dev/null && echo OK
|| echo KO
```

The command should return 'OK', else proxy settings are wrong.

3.2 Install extra packages

Required for *Developer Package* and *Distribution Package*.

In order to do basic development tasks, basic cross-compilation (via *Developer Package*) or more complex cross-compilation as OpenEmbedded does (via *Distribution Package*), some extra Ubuntu packages should be installed:

- Packages required by OpenEmbedded/Yocto (details here):



```
PC $> sudo apt-get update
PC $> sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib build-essential chrpath socat cpio python3 python3-pip python3-pexpect xz-utils debianutils iputils-ping python3-git python3-jinja2 libegl1-mesa libsdl1.2-dev pylint3 pylint xterm
PC $> sudo apt-get install make xsltproc docbook-utils fop dblatex xmlto
```

- Packages needed for some "Developer Package" use cases:

```
PC $> sudo apt-get install libncurses5-dev libncursesw5-dev libssl-dev linux-headers-generic u-boot-tools device-tree-compiler bison flex g++ libyaml-dev
```

- Package for repo (used to download the "Distribution Package" source code):

Please follow official instructions to install [repo](#)
For Ubuntu 16.04 you should use the legacy repo [old-repo-python2](#) chapter

- Some useful tools:

```
PC $> sudo apt-get install coreutils bsdmainutils sed curl bc lrzsz corkscrew cvs subversion mercurial nfs-common nfs-kernel-server libarchive-zip-perl dos2unix texi2html diffstat libxml2-utils
```

You can also install a Java Runtime Engine, this is required for [STM32CubeMX](#) and [STM32CubeProgrammer](#)

```
PC $> sudo apt-get install default-jre
```

3.2.1 Install extra packages for Android

Below information is related to the Android™ distribution

Before downloading and building the STM32MPU distribution for Android™, make sure your system meets the following requirements:

- A 64-bit Linux® environment.
- At least 150 Gbytes of free disk space. If you conduct multiple builds, even more space is required.
- At least 8 Gbytes of RAM/swap. If you are running Linux on a virtual machine, at least 16 Gbytes of RAM/swap are required.

For more details, refer to the [requirements page](#) of the AOSP website.

Use the following commands to install the packages required to build an environment for Android (Distribution Package), after having installed the required packages [listed on Android website](#):



```
sudo apt-get update
sudo apt-get install chrpath curl libxml2-utils gdisk pv python-pycryptopp python-crypto autotools-dev automake libusb-1.0-0-dev
```



To ensure USB communication (with ADB) between the host and the device, see [ADB § Device Connection](#).

To run Android-provided tests (CTS and VTS), see [Android Platform Testing](#).

At this stage: Your environment is ready for Android build, debug and test.

3.3 Additional configurations

- Allow up to 16 partitions per mmc

By default, on Linux system, a maximum of 8 partitions are allowed on mmc. All Packages (Starter Package, ...) need more than 10 partitions for the storage device. In order to extend the number of partitions per device to 16, the following options must be added to modprobe:

```
PC $> echo 'options mmc_block perdev_minors=16' > /tmp/mmc_block.conf
PC $> sudo mv /tmp/mmc_block.conf /etc/modprobe.d/mmc_block.conf
```

- Check for *locale* setup

Required for *Distribution Package*.

The *locale* setting is used by some applications/commands (including by *Distribution Package* applications/commands). Verify that the *locale* settings are as follows:

```
PC $> locale
LANG=en-US.UTF-8
```

In case the *locale* command returns a different configuration than the one shown above, it must be reconfigured as follows:

```
PC $> sudo update-locale LANG=en_US.UTF-8
```

- Add user in basics groups

The *user* login should belong to the basic Linux groups such as **disk**, **tty**, **dialout** or **plugdev**

Use the command *groups* to list groups for the current user:

```
PC $> groups
```

If needed add *user* to the missing *<groups>*:

```
PC $> sudo adduser $USER <group>
```

Then **reboot** the PC.



3.4 Setup *Git* user information

Required for *Developer Package* and *Distribution Package*.

The User Information is needed by git^[3] in case *commit* and/or *push* commands are being used :

```
PC $> git config --global user.name "Your Name"  
PC $> git config --global user.email "you@example.com"
```



4 Windows PC

Starter Package may run on Windows.

Developer Package and *Distribution Package* require a Linux environment.

Warning

ST solutions, while reportedly functional when running on a Linux Virtual machine, are only validated for Linux native setups ...

There are several ways to run Linux system on top of a Windows host PC, ST recommends to use a Virtual Machine System:

1. Install a virtual machine such as VMWare ^[4]
2. Setup a **64 bits** Ubuntu image compatible with your virtual machine

ST, in an experimental way, has also run *Developer Package* and *Distribution Package* on a WSL2 (Windows Subsystem for Linux 2); see [WSL2](#) chapter.

4.1 Virtual Machine System

4.1.1 Virtual Machine installation

ST has selected VMWare as Linux virtual machine solution.

VMWare is a commercial company specialized in virtualization solutions. The available solutions to support a virtual Linux machine on a Windows PC are:

- VMWare Workstation Player (paid solution) for commercial use (download here ^[5])
- VMWare Workstation Player (free solution) for home use (download here ^[6])

Please proceed with the installation of the virtual machine.

Before running the virtual machine, make sure the virtualization is activated in the BIOS (it should be activated by default for any retail PC).

4.1.2 Download the Ubuntu image for the virtual machine

The "osboxes.org" ^[7] website provides virtual machine images compatible with VMWare(*.vmdk).

ecosystem release v2.1.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 20.04 (64bits).**

ecosystem release v2.0.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 16.04 (64bits).**

Download the 64 bits Ubuntu image available at ^[8] and:

1. Unzip the downloaded file
2. In VMware create a virtual machine using the Ubuntu virtual disk downloaded from osboxes.org.

The recommended usage is to dedicate, at least, half of the host machine to the virtual machine:



- CPU: 2 cores at least,
- RAM: 6 Gbytes or more is a good choice (the more RAM allocated to Virtual Machine the better - the RAM allocated to Virtual Machine must be 4GB minimum),
- Network: NAT is good and an easy way to benefit form a network connection within the virtual machine.

Virutal size of virtual disk downloaded from osboxes.org is about 500GB. Even if the real size of the file of the virtual disk is less at beginning, the size could growth up to 500GB over compiling distribution package or development package.

Information

For VMware, you need first to create a default virtual machine then add the `.vmdk` file, previously downloaded.

Please refer to the [VMwarePlayer screenshot tutorial](#).

4.1.3 Launch of Ubuntu image

Warning

For "AZERTY" keyboard users:

The default keyboard configuration is "QWERTY".

In order to configure the keyboard for "AZERTY", start by opening a session (take care that the keyboard layout is QWERTY).

TIP: the password for the default user "*osboxes.org*" is "*osboxes.org*".

TIP: the '.' character is obtained by clicking '.' on an AZERTY keyboard configured in QWERTY.

Once the session is opened, click the 'En' icon on top/right of the screen, select the French ('Fr') keyboard layout and move it to the first position in the list.

Optionally the 'En' keyboard can be completely removed. If the 'Fr' option is not present, it can be added with the 'Text entry setting' menu.

Default **Credentials** of the Ubuntu are set to "**osboxes.org**" for both login and password.

Warning

Adjust screen resolution:

The (default) resolution used by the virtual machine is 800x600 (smallest available). It is not automatically adjusted to the display resolution. In order to adjust the resolution, click the "settings" icon ('toothed wheel' on top/right of the screen), then "system settings ..." > "display" and select the appropriate resolution for the display (do not to forget to click the "Apply" button on bottom/left of the "Screen Resolution Setting" window).

For a better experience with the VMware virtual machine, install "vmware-tools" in order to be able to use the clipboard to drag-and-drop and copy/paste files between VMware and Windows. A step-by-step installation procedure of **vmware-tools** is available in the document: [PreRequisite-Vmware-tools.pdf](#)

The virtual machine is up and running!

The Ubuntu setup must be finalized according recommendations provided in [Linux PC chapter](#)

Warning

USB connection's speed:



USB connection is requested for accessing STLink (debugger and serial port) and by STM32CubeProgrammer. The speed of the USB connection between Linux running in the virtual machine and the external USB devices can be severely impacted by:

- the virtual machine USB setup;
- the USB controller in the host PC;
- the USB device connected to host PC;
- any USB hub between the USB host and the USB device.

If the speed of your USB connection is too low, we suggest to:

- try different USB configurations of the virtual machine;
- connect the USB device directly on the host USB port (without any USB hub);
- try connecting the USB device to another USB port of the host (some PC have different USB controller on different USB port).

4.2 WSL2 (experimental)

Even if STMicroelectronics strongly recommends to use a Linux® environment, the *Developer Package* and *Distribution Package* works in WSL2 (Windows Sub-system Linux 2) environment. WSL is a feature provided by **Windows 10®**. ST has run unsuccessfully *Developer Package* and *Distribution Package* on WSL but successfully on WSL2. WSL2 is available on Windows 10® since build 18917.

WSL 2 is a new version of the architecture that powers the Windows Subsystem for Linux to run ELF64 Linux binaries on Windows (more details on aka.ms/wsl2).

- WSL2 - Installation :
 - To install WSL2 please read this webpage: <https://docs.microsoft.com/fr-fr/windows/wsl/wsl2-install>
 - Once WSL2 installed, jump to chapter #Linux_PC to make your WSL2 ready to run *Developer Package* and/or *Distribution Package*.
- WSL2 - Limitations :
 - WSL2 up to now (09/2019) does not support hardware such as USB devices, serial, ... (more details).
This means, STM32CubeProgrammer should be used through native Windows
 - WSL2 files are not browsable from Windows native file explorer.
To share files between WSL2 and Windows, the preferred way is to use the mount point `/mnt/c` from WSL2 and do copies.
- WSL2 - Tips :
 - Launch graphical application : On wiki.ubuntu.com the page on WSL contains a chapter Running Graphical Applications.

4.3 References

- Supported Linux Distributionsl
- [https://en.wikipedia.org/wiki/Corkscrew_\(program\)](https://en.wikipedia.org/wiki/Corkscrew_(program))
- Git
- <http://vmware.com>
- https://my.vmware.com/en/web/vmware/free#desktop_end_user_computing/vmware_workstation_player/15_0
- <https://www.vmware.com/products/workstation-player/workstation-player-evaluation.html>
- <http://osboxes.org>
- <https://www.osboxes.org/ubuntu/#ubuntu-1804-vmware>



Linux® is a registered trademark of Linus Torvalds.

Microprocessor Unit

Central processing unit

Random Access Memory (Early computer memories generally had serial access. Memories where any given address can be accessed when desired were then called "random access" to distinguish them from the memories where contents can only be accessed in a fixed order. The term is used today for volatile random-access semiconductor memories.)

Android Open Source Project

Android debug bridge (Android specific)

Compatibility Test Suite (Android specific) or Clear to send (in UART context)

Vendor Test Suite (Android specific)

ST in-circuit debugger and programmer for the STM8 and STM32 microcontroller families (See ST-LINK for more details)

Stable: 23.09.2020 - 13:22 / Revision: 12.06.2020 - 13:25

Information

Recommended setup: Native Linux PC

Contents

1 Purpose	59
2 Recommended PC configurations	60
3 Linux PC	61
3.1 Check Internet access	61
3.2 Install extra packages	62
3.2.1 Install extra packages for Android	63
3.3 Additional configurations	64
3.4 Setup <i>Git</i> user information	65
4 Windows PC	66
4.1 Virtual Machine System	66
4.1.1 Virtual Machine installation	66
4.1.2 Download the Ubuntu image for the virtual machine	66
4.1.3 Launch of Ubuntu image	67
4.2 WSL2 (experimental)	68
4.3 References	68



1 Purpose

This article explains and describes the hardware configuration required to be able to activate and run the STM32 MPU platforms.



2 Recommended PC configurations

The PC requirements depend on the [Package](#) you want to use.

The table below guides through the selection and configuration of the host PC environment according the targeted [Package](#):

Host Environment	Starter Package	Developer Package	Distribution Package
Windows (64 bits) Tested with Windows7 and Windows10 Preferred version Windows 10	native	Virtual Machine	Virtual Machine
Linux (64 bits) Tested with Ubuntu 18.04 and 20.04	native	native + additional packages (see Linux PC chapter)	native + additional packages (see Linux PC chapter)

There are no absolute minimal requirements regarding the PC hardware configuration, however ST recommends to meet or exceed the following hardware configurations when using *Developer Package* or *Distribution Package*.

The table below correspond to the minimal validated configuration:

Hardware item	Minimal validated configuration	Comments / Recommendations
CPU	core i5-2540M @ 2.6GHz 2 cores (4 threads) 3MB cache	64 bits instruction set is mandatory 8 cores/threads or more is a good config moreover for <i>Developer Package</i> and <i>Distribution Package</i> .
RAM	8GB	16GB or more is recommended especially for <i>Virtual Machine</i> setup , <i>Developer Package</i> and <i>Distribution Package</i> .
Hard Drive	320GB	1TB is probably a better config when using <i>Distribution Package</i>



3 Linux PC

A Linux PC with **Ubuntu 18.04** is the recommended setup. Other Ubuntu revisions should also be supported, please refer to Yocto Manual^[1].

i Information

ecosystem release v2.1.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 20.04 LTS).

i Information

ecosystem release v2.0.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 16.04 LTS).

3.1 Check Internet access

- **An Internet access through http and https protocols must be provided.**

Required for *Developer Package* and *Distribution Package* at least.

The command below allows to check for Internet access through http/https protocols:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```

If a 'OK' message is returned, the network is well configured. In such case, skip the rest of this section and jump to next one (Install extra packages).

Any other situation likely indicates the need for a proxy for http/https protocols.

The best solution to set a proxy for http/https protocols is via the shell variables `http_proxy` and `https_proxy`:

```
PC $> export http_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
PC $> export https_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
```

Because your password may contains "special characters" you need to translate your password into ASCII hexacode. By this way you can translate `<MyProxyPassword>` into hexacode by using this command :

```
PC $> echo -n "<MyProxyPassword>" | od -A n -t x1 -w128 | head -1 | tr " " "%"
```

Check again the Internet access with command:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```



- Internet access for *sudo* commands

Required for *Distribution Package*.

sudo commands are executed in the *root* user environment; by default, no Internet proxy settings are applied for *root* user. *Root* user should be able to browse Internet, after creation of an alias passing the proxy settings on *sudo* command:

```
PC $> alias sudo='sudo http_proxy=$http_proxy'
```

Check that the *sudo* commands is successful (requires Internet access):

```
PC $> sudo apt-get update
```

- Internet over *git://*, *ssh://* and others specifics protocols

Required for *Distribution Package*.

In addition to http/https protocols (used in 90% of the Internet traffic), some other protocols like *git://* or *ssh://* may be required.

For example in the context of the *Distribution Package*, some "git fetch" commands could require "git://" protocols".

In order to support these protocols through a proxy, the best way is to directly setup the proxy in the `$HOME/.gitconfig` file (core.gitproxy) and use a tool like *cockscrew*^[2] in order to tunnel the *git://* flow into the http flow:

```
PC $> sudo apt-get update
PC $> sudo apt-get install cockscrew

PC $> git config --replace-all --global core.gitproxy "$HOME/bin/git-proxy.sh"
PC $> git config --add --global core.gitproxy "none for <MyPrivateNetworkDomain>"
(optionnal and for example .st.com, localhost, ...)
PC $> echo 'exec cockscrew <MyProxyServerUrl> <MyProxyPort> $* $HOME/.git-proxy.auth' >
$HOME/bin/git-proxy.sh
PC $> chmod 700 $HOME/bin/git-proxy.sh
PC $> echo '<MyProxyLogin>:<MyProxyPassword>' > $HOME/.git-proxy.auth
PC $> chmod 600 $HOME/.git-proxy.auth
```

Here is a command to test this proxy settings:

```
PC $> git ls-remote git://git.openembedded.org/openembedded-core > /dev/null && echo OK
|| echo KO
```

The command should return 'OK', else proxy settings are wrong.

3.2 Install extra packages

Required for *Developer Package* and *Distribution Package*.

In order to do basic development tasks, basic cross-compilation (via *Developer Package*) or more complex cross-compilation as OpenEmbedded does (via *Distribution Package*), some extra Ubuntu packages should be installed:

- Packages required by OpenEmbedded/Yocto (details here):



```
PC $> sudo apt-get update
PC $> sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib build-essential chrpath socat cpio python3 python3-pip python3-pexpect xz-utils debianutils iputils-ping python3-git python3-jinja2 libegl1-mesa libsdl1.2-dev pylint3 pylint xterm
PC $> sudo apt-get install make xsltproc docbook-utils fop dblatex xmlto
```

- Packages needed for some "Developer Package" use cases:

```
PC $> sudo apt-get install libncurses5-dev libncursesw5-dev libssl-dev linux-headers-generic u-boot-tools device-tree-compiler bison flex g++ libyaml-dev
```

- Package for repo (used to download the "Distribution Package" source code):

Please follow official instructions to install [repo](#)
For Ubuntu 16.04 you should use the legacy repo [old-repo-python2](#) chapter

- Some useful tools:

```
PC $> sudo apt-get install coreutils bsdmainutils sed curl bc lrzsz corkscrew cvs subversion mercurial nfs-common nfs-kernel-server libarchive-zip-perl dos2unix texi2html diffstat libxml2-utils
```

You can also install a Java Runtime Engine, this is required for [STM32CubeMX](#) and [STM32CubeProgrammer](#)

```
PC $> sudo apt-get install default-jre
```

3.2.1 Install extra packages for Android

Below information is related to the Android™ distribution

Before downloading and building the STM32MPU distribution for Android™, make sure your system meets the following requirements:

- A 64-bit Linux® environment.
- At least 150 Gbytes of free disk space. If you conduct multiple builds, even more space is required.
- At least 8 Gbytes of RAM/swap. If you are running Linux on a virtual machine, at least 16 Gbytes of RAM/swap are required.

For more details, refer to the [requirements page](#) of the AOSP website.

Use the following commands to install the packages required to build an environment for Android (Distribution Package), after having installed the required packages [listed on Android website](#):



```
sudo apt-get update
sudo apt-get install chrpath curl libxml2-utils gdisk pv python-pycryptopp python-crypto autotools-dev automake libusb-1.0-0-dev
```



To ensure USB communication (with ADB) between the host and the device, see [ADB § Device Connection](#).

To run Android-provided tests (CTS and VTS), see [Android Platform Testing](#).

At this stage: Your environment is ready for Android build, debug and test.

3.3 Additional configurations

- Allow up to 16 partitions per mmc

By default, on Linux system, a maximum of 8 partitions are allowed on mmc. All Packages (Starter Package, ...) need more than 10 partitions for the storage device. In order to extend the number of partitions per device to 16, the following options must be added to modprobe:

```
PC $> echo 'options mmc_block perdev_minors=16' > /tmp/mmc_block.conf
PC $> sudo mv /tmp/mmc_block.conf /etc/modprobe.d/mmc_block.conf
```

- Check for *locale* setup

Required for *Distribution Package*.

The *locale* setting is used by some applications/commands (including by *Distribution Package* applications/commands). Verify that the *locale* settings are as follows:

```
PC $> locale
LANG=en-US.UTF-8
```

In case the *locale* command returns a different configuration than the one shown above, it must be reconfigured as follows:

```
PC $> sudo update-locale LANG=en_US.UTF-8
```

- Add user in basics groups

The *user* login should belong to the basic Linux groups such as **disk**, **tty**, **dialout** or **plugdev**

Use the command *groups* to list groups for the current user:

```
PC $> groups
```

If needed add *user* to the missing *<groups>*:

```
PC $> sudo adduser $USER <group>
```

Then **reboot** the PC.



3.4 Setup *Git* user information

Required for *Developer Package* and *Distribution Package*.

The User Information is needed by git^[3] in case *commit* and/or *push* commands are being used :

```
PC $> git config --global user.name "Your Name"  
PC $> git config --global user.email "you@example.com"
```



4 Windows PC

Starter Package may run on Windows.

Developer Package and *Distribution Package* require a Linux environment.

Warning

ST solutions, while reportedly functional when running on a Linux Virtual machine, are only validated for Linux native setups ...

There are several ways to run Linux system on top of a Windows host PC, ST recommends to use a Virtual Machine System:

1. Install a virtual machine such as VMWare ^[4]
2. Setup a **64 bits** Ubuntu image compatible with your virtual machine

ST, in an experimental way, has also run *Developer Package* and *Distribution Package* on a WSL2 (Windows Subsystem for Linux 2); see [WSL2](#) chapter.

4.1 Virtual Machine System

4.1.1 Virtual Machine installation

ST has selected VMWare as Linux virtual machine solution.

VMWare is a commercial company specialized in virtualization solutions. The available solutions to support a virtual Linux machine on a Windows PC are:

- VMWare Workstation Player (paid solution) for commercial use (download here ^[5])
- VMWare Workstation Player (free solution) for home use (download here ^[6])

Please proceed with the installation of the virtual machine.

Before running the virtual machine, make sure the virtualization is activated in the BIOS (it should be activated by default for any retail PC).

4.1.2 Download the Ubuntu image for the virtual machine

The "osboxes.org" ^[7] website provides virtual machine images compatible with VMWare(*.vmdk).

ecosystem release v2.1.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 20.04 (64bits).**

ecosystem release v2.0.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 16.04 (64bits).**

Download the 64 bits Ubuntu image available at ^[8] and:

1. Unzip the downloaded file
2. In VMware create a virtual machine using the Ubuntu virtual disk downloaded from osboxes.org.

The recommended usage is to dedicate, at least, half of the host machine to the virtual machine:



- CPU: 2 cores at least,
- RAM: 6 Gbytes or more is a good choice (the more RAM allocated to Virtual Machine the better - the RAM allocated to Virtual Machine must be 4GB minimum),
- Network: NAT is good and an easy way to benefit form a network connection within the virtual machine.

Virutal size of virtual disk downloaded from osboxes.org is about 500GB. Even if the real size of the file of the virtual disk is less at beginning, the size could growth up to 500GB over compiling distribution package or development package.



Information

For VMware, you need first to create a default virtual machine then add the `.vmdk` file, previously downloaded.

Please refer to the [VMwarePlayer screenshot tutorial](#).

4.1.3 Launch of Ubuntu image



Warning

For "AZERTY" keyboard users:

The default keyboard configuration is "QWERTY".

In order to configure the keyboard for "AZERTY", start by opening a session (take care that the keyboard layout is QWERTY).

TIP: the password for the default user "*osboxes.org*" is "*osboxes.org*".

TIP: the '.' character is obtained by clicking '.' on an AZERTY keyboard configured in QWERTY.

Once the session is opened, click the 'En' icon on top/right of the screen, select the French ('Fr') keyboard layout and move it to the first position in the list.

Optionally the 'En' keyboard can be completely removed. If the 'Fr' option is not present, it can be added with the 'Text entry setting' menu.

Default **Credentials** of the Ubuntu are set to "**osboxes.org**" for both login and password.



Warning

Adjust screen resolution:

The (default) resolution used by the virtual machine is 800x600 (smallest available). It is not automatically adjusted to the display resolution. In order to adjust the resolution, click the "settings" icon ('toothed wheel' on top/right of the screen), then "system settings ..." > "display" and select the appropriate resolution for the display (do not to forget to click the "Apply" button on bottom/left of the "Screen Resolution Setting" window).

For a better experience with the VMware virtual machine, install "vmware-tools" in order to be able to use the clipboard to drag-and-drop and copy/paste files between VMware and Windows. A step-by-step installation procedure of **vmware-tools** is available in the document: [PreRequisite-Vmware-tools.pdf](#)

The virtual machine is up and running!

The Ubuntu setup must be finalized according recommendations provided in [Linux PC chapter](#)



Warning

USB connection's speed:



USB connection is requested for accessing STLink (debugger and serial port) and by STM32CubeProgrammer. The speed of the USB connection between Linux running in the virtual machine and the external USB devices can be severely impacted by:

- the virtual machine USB setup;
- the USB controller in the host PC;
- the USB device connected to host PC;
- any USB hub between the USB host and the USB device.

If the speed of your USB connection is too low, we suggest to:

- try different USB configurations of the virtual machine;
- connect the USB device directly on the host USB port (without any USB hub);
- try connecting the USB device to another USB port of the host (some PC have different USB controller on different USB port).

4.2 WSL2 (experimental)

Even if STMicroelectronics strongly recommends to use a Linux® environment, the *Developer Package* and *Distribution Package* works in WSL2 (Windows Sub-system Linux 2) environment. WSL is a feature provided by **Windows 10®**. ST has run unsuccessfully *Developer Package* and *Distribution Package* on WSL but successfully on WSL2. WSL2 is available on Windows 10® since build 18917.

WSL 2 is a new version of the architecture that powers the Windows Subsystem for Linux to run ELF64 Linux binaries on Windows (more details on aka.ms/wsl2).

- WSL2 - Installation :
 - To install WSL2 please read this webpage: <https://docs.microsoft.com/fr-fr/windows/wsl/wsl2-install>
 - Once WSL2 installed, jump to chapter #Linux_PC to make your WSL2 ready to run *Developer Package* and/or *Distribution Package*.
- WSL2 - Limitations :
 - WSL2 up to now (09/2019) does not support hardware such as USB devices, serial, ... (more details).
This means, STM32CubeProgrammer should be used through native Windows
 - WSL2 files are not browsable from Windows native file explorer.
To share files between WSL2 and Windows, the preferred way is to use the mount point `/mnt/c` from WSL2 and do copies.
- WSL2 - Tips :
 - Launch graphical application : On wiki.ubuntu.com the page on WSL contains a chapter Running Graphical Applications.

4.3 References

- Supported Linux Distributionsl
- [https://en.wikipedia.org/wiki/Corkscrew_\(program\)](https://en.wikipedia.org/wiki/Corkscrew_(program))
- Git
- <http://vmware.com>
- https://my.vmware.com/en/web/vmware/free#desktop_end_user_computing/vmware_workstation_player/15_0
- <https://www.vmware.com/products/workstation-player/workstation-player-evaluation.html>
- <http://osboxes.org>
- <https://www.osboxes.org/ubuntu/#ubuntu-1804-vmware>



Linux® is a registered trademark of Linus Torvalds.

Microprocessor Unit

Central processing unit

Random Access Memory (Early computer memories generally had serial access. Memories where any given address can be accessed when desired were then called "random access" to distinguish them from the memories where contents can only be accessed in a fixed order. The term is used today for volatile random-access semiconductor memories.)

Android Open Source Project

Android debug bridge (Android specific)

Compatibility Test Suite (Android specific) or Clear to send (in UART context)

Vendor Test Suite (Android specific)

ST in-circuit debugger and programmer for the STM8 and STM32 microcontroller families (See ST-LINK for more details)

Stable: 23.03.2021 - 10:30 / Revision: 23.03.2021 - 10:09

Information

Recommended setup: Native Linux PC

Contents

1 Purpose	70
2 Recommended PC configurations	71
3 Linux PC	72
3.1 Check Internet access	72
3.2 Install extra packages	73
3.2.1 Install extra packages for Android	74
3.3 Additional configurations	75
3.4 Setup <i>Git</i> user information	76
4 Windows PC	77
4.1 Virtual Machine System	77
4.1.1 Virtual Machine installation	77
4.1.2 Download the Ubuntu image for the virtual machine	77
4.1.3 Launch of Ubuntu image	78
4.2 WSL2 (experimental)	79
4.3 References	79



1 Purpose

This article explains and describes the hardware configuration required to be able to activate and run the STM32 MPU platforms.



2 Recommended PC configurations

The PC requirements depend on the [Package](#) you want to use.

The table below guides through the selection and configuration of the host PC environment according the targeted [Package](#):

Host Environment	Starter Package	Developer Package	Distribution Package
Windows (64 bits) Tested with Windows7 and Windows10 Preferred version Windows 10	native	Virtual Machine	Virtual Machine
Linux (64 bits) Tested with Ubuntu 18.04 and 20.04	native	native + additional packages (see Linux PC chapter)	native + additional packages (see Linux PC chapter)

There are no absolute minimal requirements regarding the PC hardware configuration, however ST recommends to meet or exceed the following hardware configurations when using *Developer Package* or *Distribution Package*.

The table below correspond to the minimal validated configuration:

Hardware item	Minimal validated configuration	Comments / Recommendations
CPU	core i5-2540M @ 2.6GHz 2 cores (4 threads) 3MB cache	64 bits instruction set is mandatory 8 cores/threads or more is a good config moreover for <i>Developer Package</i> and <i>Distribution Package</i> .
RAM	8GB	16GB or more is recommended especially for <i>Virtual Machine</i> setup , <i>Developer Package</i> and <i>Distribution Package</i> .
Hard Drive	320GB	1TB is probably a better config when using <i>Distribution Package</i>



3 Linux PC

A Linux PC with **Ubuntu 18.04** is the recommended setup. Other Ubuntu revisions should also be supported, please refer to Yocto Manual^[1].

i Information

ecosystem release v2.1.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 20.04 LTS).

i Information

ecosystem release v2.0.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 16.04 LTS).

3.1 Check Internet access

- **An Internet access through http and https protocols must be provided.**

Required for *Developer Package* and *Distribution Package* at least.

The command below allows to check for Internet access through http/https protocols:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```

If a 'OK' message is returned, the network is well configured. In such case, skip the rest of this section and jump to next one (Install extra packages).

Any other situation likely indicates the need for a proxy for http/https protocols.

The best solution to set a proxy for http/https protocols is via the shell variables `http_proxy` and `https_proxy`:

```
PC $> export http_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
PC $> export https_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
```

Because your password may contains "special characters" you need to translate your password into ASCII hexacode. By this way you can translate `<MyProxyPassword>` into hexacode by using this command :

```
PC $> echo -n "<MyProxyPassword>" | od -A n -t x1 -w128 | head -1 | tr " " "%"
```

Check again the Internet access with command:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```




- Internet access for *sudo* commands

Required for *Distribution Package*.

sudo commands are executed in the *root* user environment; by default, no Internet proxy settings are applied for *root* user. *Root* user should be able to browse Internet, after creation of an alias passing the proxy settings on *sudo* command:

```
PC $> alias sudo='sudo http_proxy=$http_proxy'
```

Check that the *sudo* commands is successful (requires Internet access):

```
PC $> sudo apt-get update
```

- Internet over *git://*, *ssh://* and others specifics protocols

Required for *Distribution Package*.

In addition to http/https protocols (used in 90% of the Internet traffic), some other protocols like *git://* or *ssh://* may be required.

For example in the context of the *Distribution Package*, some "git fetch" commands could require "git://" protocols".

In order to support these protocols through a proxy, the best way is to directly setup the proxy in the `$HOME/.gitconfig` file (core.gitproxy) and use a tool like *cockscrew*^[2] in order to tunnel the *git://* flow into the http flow:

```
PC $> sudo apt-get update
PC $> sudo apt-get install cockscrew

PC $> git config --replace-all --global core.gitproxy "$HOME/bin/git-proxy.sh"
PC $> git config --add --global core.gitproxy "none for <MyPrivateNetworkDomain>"
(optionnal and for example .st.com, localhost, ...)
PC $> echo 'exec cockscrew <MyProxyServerUrl> <MyProxyPort> $* $HOME/.git-proxy.auth' >
$HOME/bin/git-proxy.sh
PC $> chmod 700 $HOME/bin/git-proxy.sh
PC $> echo '<MyProxyLogin>:<MyProxyPassword>' > $HOME/.git-proxy.auth
PC $> chmod 600 $HOME/.git-proxy.auth
```

Here is a command to test this proxy settings:

```
PC $> git ls-remote git://git.openembedded.org/openembedded-core > /dev/null && echo OK
|| echo KO
```

The command should return 'OK', else proxy settings are wrong.

3.2 Install extra packages

Required for *Developer Package* and *Distribution Package*.

In order to do basic development tasks, basic cross-compilation (via *Developer Package*) or more complex cross-compilation as OpenEmbedded does (via *Distribution Package*), some extra Ubuntu packages should be installed:

- Packages required by OpenEmbedded/Yocto (details here):



```
PC $> sudo apt-get update
PC $> sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib build-essential chrpath socat cpio python3 python3-pip python3-pexpect xz-utils debianutils iputils-ping python3-git python3-jinja2 libegl1-mesa libsdl1.2-dev pylint3 pylint xterm
PC $> sudo apt-get install make xsltproc docbook-utils fop dblatex xmlto
```

- Packages needed for some "Developer Package" use cases:

```
PC $> sudo apt-get install libncurses5-dev libncursesw5-dev libssl-dev linux-headers-generic u-boot-tools device-tree-compiler bison flex g++ libyaml-dev
```

- Package for repo (used to download the "Distribution Package" source code):

Please follow official instructions to install [repo](#)
For Ubuntu 16.04 you should use the legacy repo [old-repo-python2](#) chapter

- Some useful tools:

```
PC $> sudo apt-get install coreutils bsdmainutils sed curl bc lrzsz corkscrew cvs subversion mercurial nfs-common nfs-kernel-server libarchive-zip-perl dos2unix texi2html diffstat libxml2-utils
```

You can also install a Java Runtime Engine, this is required for [STM32CubeMX](#) and [STM32CubeProgrammer](#)

```
PC $> sudo apt-get install default-jre
```

3.2.1 Install extra packages for Android

Below information is related to the Android™ distribution

Before downloading and building the STM32MPU distribution for Android™, make sure your system meets the following requirements:

- A 64-bit Linux® environment.
- At least 150 Gbytes of free disk space. If you conduct multiple builds, even more space is required.
- At least 8 Gbytes of RAM/swap. If you are running Linux on a virtual machine, at least 16 Gbytes of RAM/swap are required.

For more details, refer to the [requirements page](#) of the AOSP website.

Use the following commands to install the packages required to build an environment for Android (Distribution Package), after having installed the required packages [listed on Android website](#):



```
sudo apt-get update
sudo apt-get install chrpath curl libxml2-utils gdisk pv python-pycryptopp python-crypto autotools-dev automake libusb-1.0-0-dev
```



To ensure USB communication (with ADB) between the host and the device, see [ADB § Device Connection](#).

To run Android-provided tests (CTS and VTS), see [Android Platform Testing](#).

At this stage: Your environment is ready for Android build, debug and test.

3.3 Additional configurations

- Allow up to 16 partitions per mmc

By default, on Linux system, a maximum of 8 partitions are allowed on mmc. All Packages (Starter Package, ...) need more than 10 partitions for the storage device. In order to extend the number of partitions per device to 16, the following options must be added to modprobe:

```
PC $> echo 'options mmc_block perdev_minors=16' > /tmp/mmc_block.conf
PC $> sudo mv /tmp/mmc_block.conf /etc/modprobe.d/mmc_block.conf
```

- Check for *locale* setup

Required for *Distribution Package*.

The *locale* setting is used by some applications/commands (including by *Distribution Package* applications/commands). Verify that the *locale* settings are as follows:

```
PC $> locale
LANG=en-US.UTF-8
```

In case the *locale* command returns a different configuration than the one shown above, it must be reconfigured as follows:

```
PC $> sudo update-locale LANG=en_US.UTF-8
```

- Add user in basics groups

The *user* login should belong to the basic Linux groups such as **disk**, **tty**, **dialout** or **plugdev**

Use the command *groups* to list groups for the current user:

```
PC $> groups
```

If needed add *user* to the missing *<groups>*:

```
PC $> sudo adduser $USER <group>
```

Then **reboot** the PC.



3.4 Setup *Git* user information

Required for *Developer Package* and *Distribution Package*.

The User Information is needed by git^[3] in case *commit* and/or *push* commands are being used :

```
PC $> git config --global user.name "Your Name"  
PC $> git config --global user.email "you@example.com"
```



4 Windows PC

Starter Package may run on Windows.

Developer Package and *Distribution Package* require a Linux environment.

Warning

ST solutions, while reportedly functional when running on a Linux Virtual machine, are only validated for Linux native setups ...

There are several ways to run Linux system on top of a Windows host PC, ST recommends to use a Virtual Machine System:

1. Install a virtual machine such as VMWare ^[4]
2. Setup a **64 bits** Ubuntu image compatible with your virtual machine

ST, in an experimental way, has also run *Developer Package* and *Distribution Package* on a WSL2 (Windows Subsystem for Linux 2); see [WSL2](#) chapter.

4.1 Virtual Machine System

4.1.1 Virtual Machine installation

ST has selected VMWare as Linux virtual machine solution.

VMWare is a commercial company specialized in virtualization solutions. The available solutions to support a virtual Linux machine on a Windows PC are:

- VMWare Workstation Player (paid solution) for commercial use (download here ^[5])
- VMWare Workstation Player (free solution) for home use (download here ^[6])


Please proceed with the installation of the virtual machine.

Before running the virtual machine, make sure the virtualization is activated in the BIOS (it should be activated by default for any retail PC).

4.1.2 Download the Ubuntu image for the virtual machine

The "osboxes.org" ^[7] website provides virtual machine images compatible with VMWare(*.vmdk).

ecosystem release v2.1.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 20.04 (64bits).**

ecosystem release v2.0.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 16.04 (64bits).**

Download the 64 bits Ubuntu image available at ^[8] and:

1. Unzip the downloaded file
2. In VMware create a virtual machine using the Ubuntu virtual disk downloaded from osboxes.org.

The recommended usage is to dedicate, at least, half of the host machine to the virtual machine:



- CPU: 2 cores at least,
- RAM: 6 Gbytes or more is a good choice (the more RAM allocated to Virtual Machine the better - the RAM allocated to Virtual Machine must be 4GB minimum),
- Network: NAT is good and an easy way to benefit form a network connection within the virtual machine.

Virutal size of virtual disk downloaded from osboxes.org is about 500GB. Even if the real size of the file of the virtual disk is less at beginning, the size could growth up to 500GB over compiling distribution package or development package.

Information

For VMware, you need first to create a default virtual machine then add the `.vmdk` file, previously downloaded.

Please refer to the [VMwarePlayer screenshot tutorial](#).

4.1.3 Launch of Ubuntu image

Warning

For "AZERTY" keyboard users:

The default keyboard configuration is "QWERTY".

In order to configure the keyboard for "AZERTY", start by opening a session (take care that the keyboard layout is QWERTY).

TIP: the password for the default user "*osboxes.org*" is "*osboxes.org*".

TIP: the '.' character is obtained by clicking '.' on an AZERTY keyboard configured in QWERTY.

Once the session is opened, click the 'En' icon on top/right of the screen, select the French ('Fr') keyboard layout and move it to the first position in the list.

Optionally the 'En' keyboard can be completely removed. If the 'Fr' option is not present, it can be added with the 'Text entry setting' menu.

Default **Credentials** of the Ubuntu are set to "**osboxes.org**" for both login and password.

Warning

Adjust screen resolution:

The (default) resolution used by the virtual machine is 800x600 (smallest available). It is not automatically adjusted to the display resolution. In order to adjust the resolution, click the "settings" icon ('toothed wheel' on top/right of the screen), then "system settings ..." > "display" and select the appropriate resolution for the display (do not to forget to click the "Apply" button on bottom/left of the "Screen Resolution Setting" window).

For a better experience with the VMware virtual machine, install "vmware-tools" in order to be able to use the clipboard to drag-and-drop and copy/paste files between VMware and Windows. A step-by-step installation procedure of **vmware-tools** is available in the document: [PreRequisite-Vmware-tools.pdf](#)

The virtual machine is up and running!

The Ubuntu setup must be finalized according recommendations provided in [Linux PC chapter](#)

Warning

USB connection's speed:



USB connection is requested for accessing STLink (debugger and serial port) and by STM32CubeProgrammer. The speed of the USB connection between Linux running in the virtual machine and the external USB devices can be severely impacted by:

- the virtual machine USB setup;
- the USB controller in the host PC;
- the USB device connected to host PC;
- any USB hub between the USB host and the USB device.

If the speed of your USB connection is too low, we suggest to:

- try different USB configurations of the virtual machine;
- connect the USB device directly on the host USB port (without any USB hub);
- try connecting the USB device to another USB port of the host (some PC have different USB controller on different USB port).

4.2 WSL2 (experimental)

Even if STMicroelectronics strongly recommends to use a Linux® environment, the *Developer Package* and *Distribution Package* works in WSL2 (Windows Sub-system Linux 2) environment. WSL is a feature provided by **Windows 10®**. ST has run unsuccessfully *Developer Package* and *Distribution Package* on WSL but successfully on WSL2. WSL2 is available on Windows 10® since build 18917.

WSL 2 is a new version of the architecture that powers the Windows Subsystem for Linux to run ELF64 Linux binaries on Windows (more details on aka.ms/wsl2).

- WSL2 - Installation :
 - To install WSL2 please read this webpage: <https://docs.microsoft.com/fr-fr/windows/wsl/wsl2-install>
 - Once WSL2 installed, jump to chapter #Linux_PC to make your WSL2 ready to run *Developer Package* and/or *Distribution Package*.
- WSL2 - Limitations :
 - WSL2 up to now (09/2019) does not support hardware such as USB devices, serial, ... (more details).
This means, STM32CubeProgrammer should be used through native Windows
 - WSL2 files are not browsable from Windows native file explorer.
To share files between WSL2 and Windows, the preferred way is to use the mount point `/mnt/c` from WSL2 and do copies.
- WSL2 - Tips :
 - Launch graphical application : On wiki.ubuntu.com the page on WSL contains a chapter Running Graphical Applications.

4.3 References

- Supported Linux Distributionsl
- [https://en.wikipedia.org/wiki/Corkscrew_\(program\)](https://en.wikipedia.org/wiki/Corkscrew_(program))
- Git
- <http://vmware.com>
- https://my.vmware.com/en/web/vmware/free#desktop_end_user_computing/vmware_workstation_player/15_0
- <https://www.vmware.com/products/workstation-player/workstation-player-evaluation.html>
- <http://osboxes.org>
- <https://www.osboxes.org/ubuntu/#ubuntu-1804-vmware>



Linux® is a registered trademark of Linus Torvalds.

Microprocessor Unit

Central processing unit

Random Access Memory (Early computer memories generally had serial access. Memories where any given address can be accessed when desired were then called "random access" to distinguish them from the memories where contents can only be accessed in a fixed order. The term is used today for volatile random-access semiconductor memories.)

Android Open Source Project

Android debug bridge (Android specific)

Compatibility Test Suite (Android specific) or Clear to send (in UART context)

Vendor Test Suite (Android specific)

ST in-circuit debugger and programmer for the STM8 and STM32 microcontroller families (See ST-LINK for more details)

Stable: 23.06.2020 - 14:35 / Revision: 12.06.2020 - 10:12

Information

Recommended setup: Native Linux PC

Contents

1 Purpose	81
2 Recommended PC configurations	82
3 Linux PC	83
3.1 Check Internet access	83
3.2 Install extra packages	84
3.2.1 Install extra packages for Android	85
3.3 Additional configurations	86
3.4 Setup <i>Git</i> user information	87
4 Windows PC	88
4.1 Virtual Machine System	88
4.1.1 Virtual Machine installation	88
4.1.2 Download the Ubuntu image for the virtual machine	88
4.1.3 Launch of Ubuntu image	89
4.2 WSL2 (experimental)	90
4.3 References	90



1 Purpose

This article explains and describes the hardware configuration required to be able to activate and run the STM32 MPU platforms.



2 Recommended PC configurations

The PC requirements depend on the [Package](#) you want to use.

The table below guides through the selection and configuration of the host PC environment according the targeted [Package](#):

Host Environment	Starter Package	Developer Package	Distribution Package
Windows (64 bits) Tested with Windows7 and Windows10 Preferred version Windows 10	native	Virtual Machine	Virtual Machine
Linux (64 bits) Tested with Ubuntu 18.04 and 20.04	native	native + additional packages (see Linux PC chapter)	native + additional packages (see Linux PC chapter)

There are no absolute minimal requirements regarding the PC hardware configuration, however ST recommends to meet or exceed the following hardware configurations when using *Developer Package* or *Distribution Package*.

The table below correspond to the minimal validated configuration:

Hardware item	Minimal validated configuration	Comments / Recommendations
CPU	core i5-2540M @ 2.6GHz 2 cores (4 threads) 3MB cache	64 bits instruction set is mandatory 8 cores/threads or more is a good config moreover for <i>Developer Package</i> and <i>Distribution Package</i> .
RAM	8GB	16GB or more is recommended especially for <i>Virtual Machine</i> setup , <i>Developer Package</i> and <i>Distribution Package</i> .
Hard Drive	320GB	1TB is probably a better config when using <i>Distribution Package</i>



3 Linux PC

A Linux PC with **Ubuntu 18.04** is the recommended setup. Other Ubuntu revisions should also be supported, please refer to Yocto Manual^[1].

i Information

ecosystem release v2.1.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 20.04 LTS).

i Information

ecosystem release v2.0.0 **i**

ST solutions are tested and validated on a Linux PC running Ubuntu 18.04 LTS (and Ubuntu 16.04 LTS).

3.1 Check Internet access

- **An Internet access through http and https protocols must be provided.**

Required for *Developer Package* and *Distribution Package* at least.

The command below allows to check for Internet access through http/https protocols:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```

If a 'OK' message is returned, the network is well configured. In such case, skip the rest of this section and jump to next one (Install extra packages).

Any other situation likely indicates the need for a proxy for http/https protocols.

The best solution to set a proxy for http/https protocols is via the shell variables `http_proxy` and `https_proxy`:

```
PC $> export http_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
PC $> export https_proxy=http://<MyProxyLogin>:<MyProxyPassword>@<MyProxyServerUrl>:<MyProxyPort>
```

Because your password may contains "special characters" you need to translate your password into ASCII hexacode. By this way you can translate `<MyProxyPassword>` into hexacode by using this command :

```
PC $> echo -n "<MyProxyPassword>" | od -A n -t x1 -w128 | head -1 | tr " " "%"
```

Check again the Internet access with command:

```
PC $> wget -q www.google.com && echo "Internet access over HTTP/HTTPS is OK !" || echo
"No internet access over HTTP/HTTPS ! You may need to set up a proxy."
```



- Internet access for *sudo* commands

Required for *Distribution Package*.

sudo commands are executed in the *root* user environment; by default, no Internet proxy settings are applied for *root* user. *Root* user should be able to browse Internet, after creation of an alias passing the proxy settings on *sudo* command:

```
PC $> alias sudo='sudo http_proxy=$http_proxy'
```

Check that the *sudo* commands is successful (requires Internet access):

```
PC $> sudo apt-get update
```

- Internet over *git://*, *ssh://* and others specifics protocols

Required for *Distribution Package*.

In addition to http/https protocols (used in 90% of the Internet traffic), some other protocols like *git://* or *ssh://* may be required.

For example in the context of the *Distribution Package*, some "git fetch" commands could require "git://" protocols".

In order to support these protocols through a proxy, the best way is to directly setup the proxy in the `$HOME/.gitconfig` file (core.gitproxy) and use a tool like *cockscrew*^[2] in order to tunnel the *git://* flow into the http flow:

```
PC $> sudo apt-get update
PC $> sudo apt-get install cockscrew

PC $> git config --replace-all --global core.gitproxy "$HOME/bin/git-proxy.sh"
PC $> git config --add --global core.gitproxy "none for <MyPrivateNetworkDomain>"
(optionnal and for example .st.com, localhost, ...)
PC $> echo 'exec cockscrew <MyProxyServerUrl> <MyProxyPort> $* $HOME/.git-proxy.auth' >
$HOME/bin/git-proxy.sh
PC $> chmod 700 $HOME/bin/git-proxy.sh
PC $> echo '<MyProxyLogin>:<MyProxyPassword>' > $HOME/.git-proxy.auth
PC $> chmod 600 $HOME/.git-proxy.auth
```

Here is a command to test this proxy settings:

```
PC $> git ls-remote git://git.openembedded.org/openembedded-core > /dev/null && echo OK
|| echo KO
```

The command should return 'OK', else proxy settings are wrong.

3.2 Install extra packages

Required for *Developer Package* and *Distribution Package*.

In order to do basic development tasks, basic cross-compilation (via *Developer Package*) or more complex cross-compilation as OpenEmbedded does (via *Distribution Package*), some extra Ubuntu packages should be installed:

- Packages required by OpenEmbedded/Yocto (details here):



```
PC $> sudo apt-get update
PC $> sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib build-essential chrpath socat cpio python3 python3-pip python3-pexpect xz-utils debianutils iputils-ping python3-git python3-jinja2 libegl1-mesa libsdl1.2-dev pylint3 pylint xterm
PC $> sudo apt-get install make xsltproc docbook-utils fop dblatex xmlto
```

- Packages needed for some "Developer Package" use cases:

```
PC $> sudo apt-get install libncurses5-dev libncursesw5-dev libssl-dev linux-headers-generic u-boot-tools device-tree-compiler bison flex g++ libyaml-dev
```

- Package for repo (used to download the "Distribution Package" source code):

Please follow official instructions to install [repo](#)
For Ubuntu 16.04 you should use the legacy repo [old-repo-python2](#) chapter

- Some useful tools:

```
PC $> sudo apt-get install coreutils bsdmainutils sed curl bc lrzsz corkscrew cvs subversion mercurial nfs-common nfs-kernel-server libarchive-zip-perl dos2unix texi2html diffstat libxml2-utils
```

You can also install a Java Runtime Engine, this is required for [STM32CubeMX](#) and [STM32CubeProgrammer](#)

```
PC $> sudo apt-get install default-jre
```

3.2.1 Install extra packages for Android

Below information is related to the Android™ distribution

Before downloading and building the STM32MPU distribution for Android™, make sure your system meets the following requirements:

- A 64-bit Linux® environment.
- At least 150 Gbytes of free disk space. If you conduct multiple builds, even more space is required.
- At least 8 Gbytes of RAM/swap. If you are running Linux on a virtual machine, at least 16 Gbytes of RAM/swap are required.

For more details, refer to the [requirements page](#) of the AOSP website.

Use the following commands to install the packages required to build an environment for Android (Distribution Package), after having installed the required packages [listed on Android website](#):



```
sudo apt-get update
sudo apt-get install chrpath curl libxml2-utils gdisk pv python-pycryptopp python-crypto autotools-dev automake libusb-1.0-0-dev
```



To ensure USB communication (with ADB) between the host and the device, see [ADB § Device Connection](#).

To run Android-provided tests (CTS and VTS), see [Android Platform Testing](#).

At this stage: Your environment is ready for Android build, debug and test.

3.3 Additional configurations

- Allow up to 16 partitions per mmc

By default, on Linux system, a maximum of 8 partitions are allowed on mmc. All Packages (Starter Package, ...) need more than 10 partitions for the storage device. In order to extend the number of partitions per device to 16, the following options must be added to modprobe:

```
PC $> echo 'options mmc_block perdev_minors=16' > /tmp/mmc_block.conf
PC $> sudo mv /tmp/mmc_block.conf /etc/modprobe.d/mmc_block.conf
```

- Check for *locale* setup

Required for *Distribution Package*.

The *locale* setting is used by some applications/commands (including by *Distribution Package* applications/commands). Verify that the *locale* settings are as follows:

```
PC $> locale
LANG=en-US.UTF-8
```

In case the *locale* command returns a different configuration than the one shown above, it must be reconfigured as follows:

```
PC $> sudo update-locale LANG=en_US.UTF-8
```

- Add user in basics groups

The *user* login should belong to the basic Linux groups such as **disk**, **tty**, **dialout** or **plugdev**

Use the command *groups* to list groups for the current user:

```
PC $> groups
```

If needed add *user* to the missing *<groups>*:

```
PC $> sudo adduser $USER <group>
```

Then **reboot** the PC.



3.4 Setup *Git* user information

Required for *Developer Package* and *Distribution Package*.

The User Information is needed by git^[3] in case *commit* and/or *push* commands are being used :

```
PC $> git config --global user.name "Your Name"  
PC $> git config --global user.email "you@example.com"
```



4 Windows PC

Starter Package may run on Windows.

Developer Package and *Distribution Package* require a Linux environment.

Warning

ST solutions, while reportedly functional when running on a Linux Virtual machine, are only validated for Linux native setups ...

There are several ways to run Linux system on top of a Windows host PC, ST recommends to use a Virtual Machine System:

1. Install a virtual machine such as VMWare ^[4]
2. Setup a **64 bits** Ubuntu image compatible with your virtual machine

ST, in an experimental way, has also run *Developer Package* and *Distribution Package* on a WSL2 (Windows Subsystem for Linux 2); see [WSL2](#) chapter.

4.1 Virtual Machine System

4.1.1 Virtual Machine installation

ST has selected VMWare as Linux virtual machine solution.

VMWare is a commercial company specialized in virtualization solutions. The available solutions to support a virtual Linux machine on a Windows PC are:

- VMWare Workstation Player (paid solution) for commercial use (download here ^[5])
- VMWare Workstation Player (free solution) for home use (download here ^[6])

Please proceed with the installation of the virtual machine.

Before running the virtual machine, make sure the virtualization is activated in the BIOS (it should be activated by default for any retail PC).

4.1.2 Download the Ubuntu image for the virtual machine

The "osboxes.org" ^[7] website provides virtual machine images compatible with VMWare(*.vmdk).

ecosystem release v2.1.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 20.04 (64bits).**

ecosystem release v2.0.0  : **Setup have been validated and tested on Ubuntu 18.04 (64bits) and Ubuntu 16.04 (64bits).**

Download the 64 bits Ubuntu image available at ^[8] and:

1. Unzip the downloaded file
2. In VMware create a virtual machine using the Ubuntu virtual disk downloaded from osboxes.org.

The recommended usage is to dedicate, at least, half of the host machine to the virtual machine:



- CPU: 2 cores at least,
- RAM: 6 Gbytes or more is a good choice (the more RAM allocated to Virtual Machine the better - the RAM allocated to Virtual Machine must be 4GB minimum),
- Network: NAT is good and an easy way to benefit form a network connection within the virtual machine.

Virutal size of virtual disk downloaded from osboxes.org is about 500GB. Even if the real size of the file of the virtual disk is less at beginning, the size could growth up to 500GB over compiling distribution package or development package.

Information

For VMware, you need first to create a default virtual machine then add the `.vmdk` file, previously downloaded.

Please refer to the [VMwarePlayer screenshot tutorial](#).

4.1.3 Launch of Ubuntu image

Warning

For "AZERTY" keyboard users:

The default keyboard configuration is "QWERTY".

In order to configure the keyboard for "AZERTY", start by opening a session (take care that the keyboard layout is QWERTY).

TIP: the password for the default user "*osboxes.org*" is "*osboxes.org*".

TIP: the '.' character is obtained by clicking '.' on an AZERTY keyboard configured in QWERTY.

Once the session is opened, click the 'En' icon on top/right of the screen, select the French ('Fr') keyboard layout and move it to the first position in the list.

Optionally the 'En' keyboard can be completely removed. If the 'Fr' option is not present, it can be added with the 'Text entry setting' menu.

Default **Credentials** of the Ubuntu are set to "**osboxes.org**" for both login and password.

Warning

Adjust screen resolution:

The (default) resolution used by the virtual machine is 800x600 (smallest available). It is not automatically adjusted to the display resolution. In order to adjust the resolution, click the "settings" icon ('toothed wheel' on top/right of the screen), then "system settings ..." > "display" and select the appropriate resolution for the display (do not to forget to click the "Apply" button on bottom/left of the "Screen Resolution Setting" window).

For a better experience with the VMware virtual machine, install "vmware-tools" in order to be able to use the clipboard to drag-and-drop and copy/paste files between VMware and Windows. A step-by-step installation procedure of **vmware-tools** is available in the document: [PreRequisite-Vmware-tools.pdf](#)

The virtual machine is up and running!

The Ubuntu setup must be finalized according recommendations provided in [Linux PC chapter](#)

Warning

USB connection's speed:



USB connection is requested for accessing STLink (debugger and serial port) and by STM32CubeProgrammer. The speed of the USB connection between Linux running in the virtual machine and the external USB devices can be severely impacted by:

- the virtual machine USB setup;
- the USB controller in the host PC;
- the USB device connected to host PC;
- any USB hub between the USB host and the USB device.

If the speed of your USB connection is too low, we suggest to:

- try different USB configurations of the virtual machine;
- connect the USB device directly on the host USB port (without any USB hub);
- try connecting the USB device to another USB port of the host (some PC have different USB controller on different USB port).

4.2 WSL2 (experimental)

Even if STMicroelectronics strongly recommends to use a Linux® environment, the *Developer Package* and *Distribution Package* works in WSL2 (Windows Sub-system Linux 2) environment. WSL is a feature provided by **Windows 10®**. ST has run unsuccessfully *Developer Package* and *Distribution Package* on WSL but successfully on WSL2. WSL2 is available on Windows 10® since build 18917.

WSL 2 is a new version of the architecture that powers the Windows Subsystem for Linux to run ELF64 Linux binaries on Windows (more details on aka.ms/wsl2).

- WSL2 - Installation :
 - To install WSL2 please read this webpage: <https://docs.microsoft.com/fr-fr/windows/wsl/wsl2-install>
 - Once WSL2 installed, jump to chapter #Linux_PC to make your WSL2 ready to run *Developer Package* and/or *Distribution Package*.
- WSL2 - Limitations :
 - WSL2 up to now (09/2019) does not support hardware such as USB devices, serial, ... (more details).
This means, STM32CubeProgrammer should be used through native Windows
 - WSL2 files are not browsable from Windows native file explorer.
To share files between WSL2 and Windows, the preferred way is to use the mount point `/mnt/c` from WSL2 and do copies.
- WSL2 - Tips :
 - Launch graphical application : On wiki.ubuntu.com the page on WSL contains a chapter Running Graphical Applications.

4.3 References

- Supported Linux Distributionsl
- [https://en.wikipedia.org/wiki/Corkscrew_\(program\)](https://en.wikipedia.org/wiki/Corkscrew_(program))
- Git
- <http://vmware.com>
- https://my.vmware.com/en/web/vmware/free#desktop_end_user_computing/vmware_workstation_player/15_0
- <https://www.vmware.com/products/workstation-player/workstation-player-evaluation.html>
- <http://osboxes.org>
- <https://www.osboxes.org/ubuntu/#ubuntu-1804-vmware>



Linux[®] is a registered trademark of Linus Torvalds.

Microprocessor Unit

Central processing unit

Random Access Memory (Early computer memories generally had serial access. Memories where any given address can be accessed when desired were then called "random access" to distinguish them from the memories where contents can only be accessed in a fixed order. The term is used today for volatile random-access semiconductor memories.)

Android Open Source Project

Android debug bridge (Android specific)

Compatibility Test Suite (Android specific) or Clear to send (in UART context)

Vendor Test Suite (Android specific)

ST in-circuit debugger and programmer for the STM8 and STM32 microcontroller families (See [ST-LINK](#) for more details)