



## CRC device tree configuration



## Contents

---

1. CRC device tree configuration .....	3
2. Device tree .....	5
3. How to assign an internal peripheral to a runtime context .....	5
4. STM32CubeMX .....	5
5. CRC internal peripheral .....	5



# CRC device tree configuration

Stable: 13.05.2020 - 08:24 / Revision: 13.05.2020 - 08:20

## Contents

1 Article purpose .....	3
2 DT bindings documentation .....	3
3 DT configuration .....	3
<b>3.1 DT configuration (STM32 level) .....</b>	<b>3</b>
<b>3.2 DT configuration (board level) .....</b>	<b>4</b>
<b>3.3 DT configuration examples .....</b>	<b>4</b>
4 How to configure the DT using STM32CubeMX .....	4
5 References .....	4

## 1 Article purpose

The purpose of this article is to explain how to configure the *CRC*<sup>[1]</sup> when the peripheral is assigned to Linux®OS.

The configuration is performed using the **device tree mechanism**<sup>[2]</sup>.

The *Device tree* provides a hardware description of the *CRC*<sup>[1]</sup>, used by *STM32 CRC Linux driver*.

If the peripheral is assigned to another execution context, refer to *How to assign an internal peripheral to a runtime context* article for guidelines on peripheral assignment and configuration.

## 2 DT bindings documentation

The *CRC*<sup>[1]</sup> is represented by the *STM32 CRC device tree bindings*<sup>[3]</sup>

## 3 DT configuration

This hardware description is a combination of STM32 microprocessor and board device tree files. See *Device tree* for explanations on device tree file split.

The **STM32CubeMX** can be used to generate the board device tree. Refer to [#How\\_to\\_configure\\_the\\_DT\\_using\\_STM32CubeMX](#) for more details.

### 3.1 DT configuration (STM32 level)

The CRC node is declared in *stm32mp151.dtsi*<sup>[4]</sup>. It provides the hardware registers base address and the clock.

```
crc1: crc@58009000 {
    compatible = "st,stm32f7-crc";
    reg = <0x58009000 0x400>;
    clocks = <&rcc CRC1>;
    status = "disabled";
};
```



This device tree part is related to STM32 microprocessors. It should be kept as is, without being modified by the end-user.

## 3.2 DT configuration (board level)

This part is used to enable the CRC used on a board. This is done by setting the **status** property to **okay**.

## 3.3 DT configuration examples

```
&crc1 {
    status = "okay";
};
```

# 4 How to configure the DT using STM32CubeMX

The [STM32CubeMX](#) tool can be used to configure the STM32MPU device and get the corresponding platform configuration device tree files.

The [STM32CubeMX](#) may not support all the properties described in the above [DT bindings](#) documentation paragraph. If so, the tool inserts **user sections** in the generated device tree. These sections can then be edited to add some properties and they are preserved from one generation to another. Refer to [STM32CubeMX](#) user manual for further information.

# 5 References

Please refer to the following links for additional information:

- [1.01.11.2](#) CRC internal peripheral
- [Device tree](#)
- [Documentation/devicetree/bindings/crypto/st,stm32-crc.txt](#)
- [STM32MP151](#) device tree file



Cyclic redundancy check calculation unit

Operating System

Device Tree

## Permission error

---

*Stable: 04.02.2020 - 07:47 / Revision: 04.02.2020 - 07:34*

You do not have permission to read this page, for the following reason:

The action "Read pages" for the draft version of this page is only available for the groups ST\_editors, ST\_readers, Selected\_editors, sysop, reviewer

## Permission error

---

*Stable: 22.06.2020 - 09:50 / Revision: 22.06.2020 - 09:49*

You do not have permission to read this page, for the following reason:

The action "Read pages" for the draft version of this page is only available for the groups ST\_editors, ST\_readers, Selected\_editors, sysop, reviewer

## Permission error

---

*Stable: 31.01.2020 - 13:04 / Revision: 31.01.2020 - 13:02*

You do not have permission to read this page, for the following reason:

The action "Read pages" for the draft version of this page is only available for the groups ST\_editors, ST\_readers, Selected\_editors, sysop, reviewer

## Permission error

---

*Stable: 12.02.2020 - 16:39 / Revision: 12.02.2020 - 16:37*

You do not have permission to read this page, for the following reason:

The action "Read pages" for the draft version of this page is only available for the groups ST\_editors, ST\_readers, Selected\_editors, sysop, reviewer