

I2S Linux driver

Stable: 18.02.2019 - 19:00 / Revision: 31.01.2019 - 07:52

A [quality version](#) of this page, [approved](#) on *18 February 2019*, was based off this revision.
It was rated: **Expert:** Approved **Technical writer:** Approved **Maintainer:** Approved

Contents

1 Article purpose	1
2 Short Description	1
3 Configuration	1
3.1 Kernel Configuration	1
3.2 Device tree	2
4 How to use	2
5 How to trace and debug	2
6 Source code location	2
7 References	2

1 Article purpose

This article introduces the I2S Linux[®] driver for the [SPI/I2S internal peripheral](#).

2 Short Description

The I2S Linux driver is an ASoC CPU DAI driver implemented in the Linux [ALSA framework](#).

3 Configuration

3.1 Kernel Configuration

Activate the I2S Linux driver in the kernel configuration using the Linux Menuconfig tool: [Menuconfig or how to configure kernel](#).

```
[*] Device Drivers
  [*] Sound card support
    [*] Advanced Linux Sound Architecture
      [*] ALSA for SoC audio support
        STMicroelectronics STM32 SOC audio support
          [*] STM32 I2S interface (SPI/I2S block) support
```

3.2 Device tree

Refer to the I2S device tree configuration article when configuring the I2S Linux kernel driver.

4 How to use

The I2S Linux driver can be accessed from userland through an ALSA device. Refer to [ALSA overview](#) for information on how to list and use ALSA devices.

5 How to trace and debug

The [debugfs](#) and procfs file system can be checked to get information on the I2S driver and the resources it uses. A non-exhaustive list of these file system entries is provided below. Refer to [ALSA overview](#) for more details on debugging tools.

- debugfs entries:
 - **asoc**: refer to [ALSA_overview#How_to_monitor](#)
 - **clk**: refer to [Clock_overview#How_to_monitor_with_debugfs](#) to get information on clocks.
 - **pinctrl**: refer to [Pinctrl_overview#How_to_monitor](#) to get information on pins.
 - **regmap**: allow to monitor SPI/I2S peripheral registers.

```
$ cat /sys/kernel/debug/regmap/xxx.audio-controller/registers
```

- procfs entries:
 - **asound**: refer to [ALSA_overview#How_to_debug](#)
 - **interrupts**: allow to check interrupts.

```
$ cat /proc/interrupts
```

6 Source code location

[sound/soc/stm/stm32_i2s.c](#) : implements the I2S Linux driver.

7 References
