

# SPDIFRX internal peripheral

Stable: 11.02.2019 - 12:21 / Revision: 21.01.2019 - 16:35

## Contents

1 Article purpose .....	1
2 Peripheral overview .....	1
2.1 Features .....	1
2.2 Security support .....	2
3 Peripheral usage and associated software .....	2
3.1 Boot time .....	2
3.2 Runtime .....	2
3.2.1 Overview .....	2
3.2.2 Software frameworks .....	2
3.2.3 Peripheral configuration .....	2
3.2.3.1 Configuration in Cortex-A7 non-secure software .....	3
3.2.3.2 Arm <sup>®</sup> Cortex <sup>®</sup> -M4 software configuration .....	3
3.2.4 Peripheral assignment .....	3
4 How to go further .....	3
5 References .....	4

## 1 Article purpose

The purpose of this article is to:

- briefly introduce the SPDIFRX peripheral and its main features
- indicate the level of security supported by this hardware block
- explain how each instance can be allocated to the three runtime contexts and linked to the corresponding software components
- explain how to configure the SPDIFRX peripheral.

## 2 Peripheral overview

The **SPDIFRX** peripheral, is designed to receive an S/PDIF flow compliant with IEC-60958 and IEC-61937. The SPDIFRX receiver provides two separated paths to retrieve the audio data and the user and channel information.

### 2.1 Features

Refer to the [STM32MP15 reference manuals](#) for the complete feature list, and to the software components, introduced below, to see which features are implemented.

## 2.2 Security support

---

The SPDIFRX is a **non secure** peripheral.

## 3 Peripheral usage and associated software

---

### 3.1 Boot time

---

The SPDIFRX is not used at boot time.

### 3.2 Runtime

---

#### 3.2.1 Overview

---

The SPDIFRX instance can be allocated to:

- the Arm<sup>®</sup> Cortex<sup>®</sup>-A7 non-secure for use in Linux with [ALSA framework](#)
- the Cortex-M4 for use in STM32Cube with [STM32Cube SPDIFRX driver](#)

Chapter [#Peripheral assignment](#) exposes which instance can be assigned to which context.

#### 3.2.2 Software frameworks

---

Do mai n	Peri phe ral	Software frameworks			Comment
		Cortex-A7 secure (OP-TEE)	Cortex-A7 non-secure (Linux)	Cortex-M4 (STM32Cube)	
Audi o	SPDI FRX		ALSA framework	STM32Cube SPDIFRX driver	

#### 3.2.3 Peripheral configuration

---

The configuration is applied by the firmware running in the context to which the peripheral is assigned. The configuration can be done alone via the [STM32CubeMX](#) tool for all internal peripherals, and then manually completed (particularly for external peripherals), according to the information given in the corresponding software framework article.

### 3.2.3.1 Configuration in Cortex-A7 non-secure software


When the Arm® Cortex®-A7 core operates in non-secure access mode, the SPDIFRX is controlled by the Linux kernel framework. Refer to the [SPDIFRX Linux driver](#) to drive the SPDIFRX through Linux kernel [ALSA framework](#). Refer to [Soundcard configuration](#) and [SPDIFRX device tree configuration](#) to configure the SPDIFRX through Linux kernel device tree<sup>[1]</sup>.

### 3.2.3.2 Arm® Cortex®-M4 software configuration

### 3.2.4 Peripheral assignment

**Check boxes** illustrate the possible peripheral allocations supported by [STM32 MPU Embedded Software](#):

- means that the peripheral can be assigned (  ) to the given runtime context.
- is used for system peripherals that cannot be unchecked because they are statically connected in the device.



Refer to [How to assign an internal peripheral to a runtime context](#) for more information on how to assign peripherals manually or via [STM32CubeMX](#).

The present chapter describes STMicroelectronics recommendations or choice of implementation. Additional possibilities might be described in [STM32MP15 reference manuals](#).

Do main	Peripheral	Runtime allocation			Comment
		Instance	Cortex-A7 secure (OP-TEE)	Cortex-A7 non-secure (Linux)	
Audio	SPDIFRX	SPDIFRX	<input type="checkbox"/>	<input type="checkbox"/>	Assignment (single choice)

## 4 How to go further

The [STM32H7 SPDIFRX training](#) <sup>[2]</sup>, introduces the STM32 S/PDIF Receiver interface on the STM32H7. This training also applies to the STM32 MPU SPDIFRX internal peripheral.

## 5 References

---

1. [↑ Device tree](#)
2. [↑ STM32H7 SPDIFRX training](#)

Sony/Philips Digital Interface Format

Open Portable Trusted Execution Environment

Microprocessor Unit