



How to transfer a file over network



# How to transfer a file over network

Stable: 24.06.2020 - 14:20 / Revision: 10.04.2020 - 15:11

## Contents

1 Article purpose .....	2
2 Introduction .....	2
3 Installation on your target .....	2
4 Installation on your PC .....	2
5 Getting started .....	3
6 References .....	3

## 1 Article purpose

The article aims to give some information useful to start with the `scp` Linux command.

## 2 Introduction

The `scp`<sup>[1]</sup> copies files between hosts on a network. It uses `ssh`<sup>[2]</sup> (remote login program) for data transfer, uses the same authentication and provides the same security as `ssh`.

This article focuses on the file transfer between a host PC and a STMicroelectronics board over a network connection.

## 3 Installation on your target

The `scp` is installed on the STMicroelectronics images via the package `openssh`.

## 4 Installation on your PC

The package `openssh-client` must be installed on your host PC to perform a file transfer over network with the `scp`.

On Ubuntu:

```
PC $> sudo apt-get install openssh-client
```



## 5 Getting started

- Your host PC and your board are connected to your local network through
  - the [STM32MP157C-EV1 Evaluation board CN3 Ethernet connector](#)
  - the [STM32MP157X-DKX Discovery kit CN8 Ethernet connector](#)
- The board IP address (*<board ip address>*) has been retrieved thanks to the *ip* Linux command line
- **Upload a file** (*<host file path>/<example.txt>*) **from your host PC to your board:**

```
PC $> scp <host file path>/<example.txt> root@<board ip address>:/<board file path>/
```

```
Example (assuming that <board ip address> is a.b.c.d):  
Copy the example.txt host PC file in the /home/root/ board directory  
PC $> echo "scp example: from host PC to board" > ./example.txt  
PC $> scp ./example.txt root@a.b.c.d:/home/root
```

```
Check the result on the board  
Board $> cat /home/root/example.txt  
scp example
```

- Download a file (*/<board file path>/<example.txt>*) from your board to your host PC:

```
PC $> scp root@<board ip address>:/<board file path>/<example.txt> <host file path>/
```

```
Example (assuming that <board ip address> is a.b.c.d):  
Copy the example.txt board file in the current directory of the host PC  
Board $> echo "scp example: from board to host PC" > /home/root/example.txt  
PC $> scp root@a.b.c.d:/home/root/example.txt ./
```

```
Check the result on the host PC  
Board $> cat ./example.txt  
scp example: from board to host PC
```

## 6 References

- [scp - Linux man page](#)
- [ssh - Linux man page](#)